


HygroMATIK®

FlexLine

Control Climate



Manual



FL-T.EN
E-8881166

Certain computer programs contained in this product [or device] were developed by HygroMatik GmbH ("the Work(s)").

Copyright © HygroMatik GmbH [16.02.2018]

FlexLine Control

All Rights reserved.

Current version of this manual can be found at: www.hygromatik.co.uk

HygroMatik GmbH grants the legal user of this product [or device] the right to use the Work(s) solely within the scope of the legitimate operation of the product [or device]. No other right is granted under this licence. In particular and without prejudice to the generality of the foregoing, the Work(s) may not be used, sold, licensed, transferred, copied or reproduced in whole or in part or in any manner or form other than as expressly granted here without the prior written consent of HygroMatik GmbH.

Information in this manual is subject to change or alteration without prior notice.

 WARNING**Risk of electrical shock!**

Hazardous electrical high voltage!

All electrical work to be performed by certified expert staff (electricians or expert personnel with equivalent training) only.

1. Introduction	5
1.1 Typographic Distinctions	5
1.2 Documentation	5
1.3 Symbols in Use	5
1.3.1 Specific Symbols related to Safety Instructions	5
1.3.2 General Symbols	5
2. Safety Instructions	7
2.1 Guidelines for Safe Operation	7
2.1.1 Scope	7
2.1.2 Unit control	7
2.1.3 Unit Operation	7
2.1.4 Mounting, dismantling, maintenance and repair of the unit	8
2.1.5 Electrical	8
2.2 Disposal after dismantling	8
3. Description of control	9
3.1 General description	9
3.2 Layout of control	9
3.3 Mainboard	10
3.3.1 Connections on the mainboard	11
3.4 Expansion board	12
3.4.1 Connections on the expansion board	12
3.5 Relay circuit board	13
3.5.1 Connections on the relay board	13
3.6 Electrical connection	14
3.6.1 Connection of control voltage	14
3.6.2 Connection of interlock (safety) system	14
3.6.3 1 step operation	14
3.6.4 Operation with external controller or active humidity sensor	15
3.6.5 Connecting the digital input (DI)	15
3.6.6 Wiring for control signal and release signal for multiple units	15
4. Screen	16
5. Operation of control	18
5.1 Operation basics	18
5.2 Screen 1 - Commissioning	20
5.2.1 Setting the language	20
5.2.2 Input of date and time	20
5.2.3 Control settings	21
5.2.4 Line-up of the initial operation parameters	22
5.3 Screen 2 - Main screen	23
5.4 Password entry	25
5.5 Screen 3 - Main menu (user level)	26
5.6 User level submenus	26
5.6.1 Settings submenu	28

5.6.2 Read values submenu	29
5.6.3 History submenu	32
5.7 Screen 3 - Main menu (operator level)	35
5.8 Operator level submenus	35
5.8.1 Settings submenu	36
5.8.2 Read values submenu	36
5.8.3 Control submenu	37
5.8.4 Service submenu	38
5.8.5 History submenu	40
5.8.6 Blow-down submenu	41
5.8.7 Fill parameters submenu	41
5.8.8 Functions submenu	42
5.8.9 Communication interface submenu	44
5.8.10 Timer submenu	45
5.8.11 Recording submenu	46
5.8.12 Relay extension 1 submenu	48
5.8.13 Relay extension 2 submenu	49
6. Faults and Warnings	53
6.1 Fault Management	53
6.1.1 Table of Fault Messages, possible Causes and Countermeasures	53
6.2 Servicemessages and warnings	59
6.3 Table of functional disruptions	60
7. Wiring Diagramms	64
7.1 FLE Single cylinder units	64
7.2 FLE Double cylinder units	70
7.3 FLH Single cylinder units	76
7.3.1 FLH Doppelzylindergeräte	79
7.4 FLH Double cylinder units	82
8. Glossary	84
9. Technical Data	89

1. Introduction

Dear Customer,

Thank you for choosing a HygroMatik steam humidifier.

HygroMatik steam humidifiers represent the latest in humidification technology.

In order to operate your HygroMatik steam humidifier safely, properly and efficiently, please read these operating instructions.

Employ your steam humidifier only in sound condition and as directed. Consider potential hazards and safety issues and follow all the recommendations in these instructions.

If you have additional questions, please contact your expert dealer.

For all technical questions or spare parts orders, please be prepared to provide unit type and serial number (see name plate on the unit).

1.1 Typographic Distinctions

- Preceded by a bullet: general specifications
- » Preceded by an arrow: procedures for servicing or maintenance which should or must be performed in the indicated order
- ☑ Installation step which must be checked off.
- italics* Terms used with graphics or drawings

1.2 Documentation

Validity:

This documentation is valid for the control built in the FlexLine unit series with the following designations:

FLExx-T

Flexline unit type: Electrode Steam Humidifier (ELDB)

FLHxx-T

Flexline unit type: Heater Steam Humidifier (HKDB)

Retention

Please retain these operating instructions in a secure, always accessible location. If the product is resold, turn the documentation over to the new operator. If the documentation is lost, please contact HygroMatik.

Versions in Other Languages

These operating instructions are available in several languages. If interested, please contact HygroMatik or your HygroMatik dealer.

1.3 Symbols in Use

1.3.1 Specific Symbols related to Safety Instructions

According to ANSI Z535.6 the following signal words are used within this document:

⚠ DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

⚠ WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

1.3.2 General Symbols

Please note

This symbol is used whenever a situation requires special attention beyond the scope of safety instructions.

Intended Use

The control described is an integral part of a HygroMatik steam humidifier. Use for other applications is not permitted. All instructions on intended use, which are given in connection with the basic device, apply.

Proper usage also comprises the adherence to the conditions specified by HygroMatik for:

- installation
- dismantling
- reassembly
- commissioning
- operation
- maintenance
- disposal

Only qualified and authorised personnel may operate the unit. Persons transporting or working on the unit must have read and understood the corresponding parts of the Operation and Maintenance Instructions and especially the chapter 2. „Safety Notes“. Additionally, operating personnel must be informed of any possible dangers. You should place a copy of the Operation and Maintenance Instructions at the unit's operational location (or near the unit).

By construction, HygroMatik steam humidifiers are not qualified for exterior application.

⚠ WARNING

Risk of scalding!

Steam with a temperature of up to 100 °C is produced.

Do not inhale steam directly!

2. Safety Instructions

These safety instructions are required by law. They promote workplace safety and accident prevention.

2.1 Guidelines for Safe Operation

2.1.1 Scope

Comply with the accident prevention regulation „DGUV Regulation 3“ to prevent injury to yourself and others. Beyond that, national regulations apply without restrictions.

2.1.2 Unit control

Do not perform any work which compromises the safety of the unit. Obey all safety instructions and warnings present on the unit.

In case of a malfunction or electrical power disruption, switch off the unit immediately and prevent a restart. Repair malfunctions promptly.

⚠ WARNING

Restricted use.

IEC 60335-1 stipulates as follows:

This device may be used by children of eight years of age and above as well as by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge so long as they are supervised or have been instructed regarding the safe use of the device and understand the hazards that may result from it. Cleaning and user maintenance of the unit must not be undertaken by children without supervision.

2.1.3 Unit Operation

⚠ WARNING

Risk of scalding!

Uncontrolled hot steam escape in case of leaking or defective components possible. Switch off unit immediately.

NOTICE

Risk of material damage!

The unit may be damaged if switched on repeatedly following a malfunction without prior repair.

Rectify defects immediately!

The unit must not be operated on a DC power supply.

The unit may only be used connected to a steam pipe that safely transports the steam.

Regularly check that all safety and monitoring devices are functioning normally. Do not remove or disable safety devices.

2.1.4 Mounting, dismantling, maintenance and repair of the unit

NOTICE

The HygroMatik steam humidifier is IP20 protected. Make sure that the unit is not object to dripping water in the mounting location.

Installing a humidifier in a room without water discharge requires safety devices to protect against water leakages.

- Use genuine spare parts only
- After any repair work, have qualified personnel check the safe operation of the unit
- Attaching or installing of **additional components** is permitted only with the **written consent** of the manufacturer

2.1.5 Electrical

⚠ WARNING

Risk of electrical shock!

Hazardous electrical voltage!

Any work on the electrical system to be performed by certified expert staff (electricians or expert personnel with comparable training) only.

Disconnect unit components from electrical power supply prior to work.

After electrical installation or repair work, test all safety mechanisms (such as grounding resistance).

NOTICE

Use only original fuses with the appropriate amperage rating.

Regularly check the unit's electrical equipment. Promptly repair any damage such as loose connections or burned wiring.

Responsibility for intrinsically safe installation of the HygroMatik steam humidifiers is incumbent on the installing specialist company.

2.2 Disposal after dismantling

NOTICE

The operator is responsible for the disposal of unit components as required by law.

3. Description of control

3.1 General description

The control is integrated into the steam humidifier and is operated via a 3.5" graphic display on the front of the unit.

The only other operating element, which is also located on the front of the unit, is a control switch whose positions are assigned as follows:

Pos. "0": The unit is switched off

Pos. "I": The unit is switched on and the control is active

Pos. "II": The cylinder water is pumped off manually without the participation of the control. The control is not active, the display remains dark.

Control switch




The relay boards are connected to the mainboard via a plug system.

The DIN rail relays are connected via cables with plug. 2 additional relay modules can be used, with 2 relays each.

For use with double cylinder units, an expansion board is added to the mainboard.

The fuse protection of the control voltage for all boards with 2 x 2.5 A fast (F1, F2) takes place on the mainboard.

The external circuitry for the control voltage and the interlock (safety) system are connected directly to the mainboard on plug ST1. If additional boards are connected, the connection moves from the mainboard to the outermost board (see sketch).



By changing the parameters, the user/operator can adapt the control to the system specifications and the special characteristics relating to the use of the unit.


Details of the operation of the unit are provided in the Glossary (see Section 6).

3.2 Layout of control

The control consists of the 3.5" screen and the mainboard. The mainboard can be expanded for additional functions with one or 2 relay boards (with 3 relays each) and additional optional relays in DIN rail format.

3.3 Mainboard

The mainboard is "the heart" of the control. All logic functions and control operations for the steam humidifier are provided here. The relays for the control of the main contactor, inlet solenoid valve and blow-down pump are included directly on the mainboard.



3.3.1 Connections on the mainboard

The use of the connections is illustrated by the wiring diagrams (see chapter 7)

3.3.1.1 Customer-side computer interfaces

Inputs

ST08:

- Control signal input 0...10 VDC
- Control signal input 0...20 mA
- Control signal input 0...140 ohm
- Configurable digital input 12 VDC

Outputs

ST03:

- Potential free break/make contacts NC and NO, programmable, relay assigned to "Collective fault" in factory setting

ST10.1/ST10.2:

- Connection options for an optional relay each in DIN rail version with wiring harness (order option)

ST07:

Control output 0...10 VDC (max. 8 mA)

ST08:

- +20 VDC supply voltage (max. 20 mA) for humidity sensors

ST15:

- Tap for 1,2 and N (unsecured) for customer use

USB:

Connection for USB stick for use as a data logger and for parameter updates

3.3.1.2 System-side interfaces

ST1:

- 4-pin screw / plug connection for the connection of L1 and N and the interlock (safety) system

ST11.1:

- +12 V, GND, CAN-Bus

Inputs

ST09:

- Input for current transformer (ELDB) / level control (HKDB) with automatic detection (for explanation of terms see Glossary, Index 7)

ST04-B:

- Galvanically isolated input (optical coupler) for sensor electrode

Outputs

ST04-A:

- Main contactor

ST05:

- Blow-down pump

ST06:

- Inlet solenoid valve

Bi-directional

ST12.1:


- Serial interface for screen connection

ST 13:

- Base for adapter board with RS485 interface

3.4 Expansion board

The expansion board is used with double cylinder units.



*) The DIP switches are for CAN-Bus address setting. They are factory preset according to the unit configuration.

3.4.1 Connections on the expansion board

3.4.1.1 Customer-side computer interfaces

Inputs/outputs

ST05:

Not used

3.4.1.2 System-side interfaces

ST1.1:

- 4-pin screw / plug connection for the connection of L1 and N and the inter-lock (safety) system

ST1.2:

- Loop-through of ST1.1

ST07:

- +12 V, GND, CAN-Bus

ST08:

Loop-through of ST07

Inputs

ST06:

- Input for current transformer (ELDB) / level control (HKDB) with automatic detection

Outputs

ST02-A:

- Main contactor

ST03:

- Blow-down pump


ST04:

Inlet solenoid valve

3.5 Relay circuit board

The relay board has three additional relays with potential free break/make contacts (contact load 250 VAC/8 A) for switching or

controlling of additional functional units or options. A maximum of 2 relay boards can be installed.



*)The DIP switches are for CAN-Bus address setting. They are factory preset according to the unit configuration

3.5.1 Connections on the relay board

3.5.1.1 Customer-side computer interfaces

Inputs

ST05:

- Configurable digital input 12 VDC

Outputs

ST02:

- Potential free break/make contacts NC and NO, programmable

ST03:

- Potential free break/make contacts NC and NO, programmable

ST04:

- Potential free break/make contacts NC and NO, programmable

3.5.1.2 System-side interfaces

ST11:

- 4-pin screw / plug connection for the connection of L1 and N and the inter-lock (safety) system

ST1.2:

- Loop-through of ST11

ST08:

- +12 V, GND, CAN-Bus

ST07:

- Loop-through of ST08

3.6 Electrical connection

⚠ WARNING

Danger of electric shock!

Dangerous electric voltage!

All work relating to the electrical installation may only be carried out by designated specialist personnel (electrician or qualified person with equivalent training).

Please note

The customer is responsible for monitoring the qualifications of the specialist personnel.

NOTICE

Potential component damage due to electrostatic discharge!

To protect the sensitive electronic components, measures to prevent damage due to electrostatic discharge must be taken before the start of the installation work.

3.6.1 Connection of control voltage

The control voltage of 230 VAC is to be applied to the board which is closest to the cable gland on the underside of the housing. The plug designation differs depending on the level of expansion:

Type of board	Plug designation
Mainboard	ST1
Expansion board	ST1.1
Relay circuit board	ST11

The pin assignment is identical for all plugs. L and N are labelled on the plugs.

3.6.2 Connection of interlock (safety) system

⚠ WARNING


Danger of electric shock!

Dangerous electric voltage!

After the initial operation of the unit, a

230VAC voltage is present at terminal 1 when standard wiring is used.

The so-called interlock (safety) system is located between terminals 1 and 2. Safety equipment can be wired (also in series) into the interlock (safety) system. If the interlock (safety) system is open, the humidifier does not start or the operation is interrupted.



Terminals 1/2 on the mainboard (socket ST1)
provided for connection of the interlock
(safety) system

Please note

The interlock (safety) system is not closed when delivered ex-factory!


Please note

The contacts, which are connected to terminals 1 and 2 must be potential free and suitable for switching of 230 VAC.

In air conditioning, it is standard to incorporate a max. hygrostat in the interlock (safety) system. The max. hygrostat is used as a safety feature in case of a malfunction of the humidity sensor.

3.6.3 1 step operation

The operation of the steam humidifier is controlled via terminals 3 and 5 by the contact which is to be provided on-site. The contact only has to be suitable for low voltage.




Terminals 3/5 on the mainboard (socket ST08)
provided for 1-step operation


3.6.4 Operation with external controller or active humidity sensor

When the steam humidifier is controlled via an external controller (e.g. a PLC) or an active humidity sensor, physical control signals can be processed in the range 0...10 V, 0...20 mA or 0...140 Ω. A separate terminal is provided on the board for each of these signal types (also see chapter 7, „Wiring diagrams“). Terminal 4, "GND" is the reference potential in each case.


Wiring for an **external controller e.g. 0...10V**:



Wiring for an **external controller e.g. 0...20mA**:



Wiring of the **humidity sensors** (e.g.: 0...10V) must be as following:



Please note

Humidity sensors require an external supply


voltage. 20 VDC are available for this purpose at terminal 3.

3.6.5 Connecting the digital input (DI)

The digital input on the mainboard can be used for switching functions.

The digital input must be wired on-site in accordance with its use, e.g. with as push-button or a switch (also see chapter 5.8.8 „Function parameters“).

Wiring the **digital input (DI)**:




Terminals 3/8 on the mainboard (socket ST08) provided for connecting the digital input

3.6.6 Wiring for control signal and release signal for multiple units

In the case of multiple units, separate humidifiers work together. The control signal and the release signal are connected to the master unit as described above. In addition, connecting cables are established between the master unit and the slave unit(s) (provided on-site). These provide the slave unit with a control signal from the master and the transmitted (potential free) release signal.


The wiring for the control signal and release signal must be implemented as follows for multiple units:











1) „ST07“ designates the connector plug on the mainboard









2) „K20“ is the relay used for the connection of the successing unit with the installed option (CN-07-10012) or the enclosed option (CN-07-10002)

4. Screen



Active screen area	Use
	Main display for operating values, navigation using the scroll keys ^{*)} .
 ^{*)}	Scroll buttons can be used to display the following operating values: <ul style="list-style-type: none"> • Humidity_actual_value [%] • Humidity_set-value [%] ^{1),2)} ; touching it opens a screen keyboard ^{*)} that allows for changing the set value • Steam_actual_unit [kg/h] • Steam_output_max. [%] • Demand [%] • Control_signal_internal [%] • Output_signal • Current_actual_cyl. 1[A] (Electrode steam humidifiers only) • Current_actual_cyl. 2 [A] (Electrode steam humidifier double cyl. units only) • Waterlevel_cyl. 1 [mm] (Heater steam humidifiers only) • Waterlevel_cyl. 2 [mm] (Heater steam humidifier double cylinder units only) ¹⁾ only when „PI controller“ is set ²⁾ not in „Weekly timer“ mode; exemption: when „ECO“ is selected as the steam production mode, the humidity set-value is output in „Weekly timer“ mode as well.
^{**)} 	Screen keyboard for changing the humidity set value; is displayed when the humidity set value display is touched; allows direct changing of the set value. Saving of the input by touching the confirmation tick in the upper right corner, exit without saving by touching the „X“ in the upper left corner.
	Button to call up set-up mode (via password). Password „000“ -> operating functions of user level (see Section 5.5) Password „010“ -> operating functions of operator level (see Section 5.7)

Active screen area	Use
  	In the event of a fault or a service message, the relevant display field is shown instead of the HygroMatik logo. Touching it opens the unit info screen (see Section 5.9).
	Unit info screen (see Section 5.9) for the display of error and service messages in plain text. Is displayed by touching the error or service message.

Icon	Status	Meaning
	dark bright flashes	Steam generation active No steam generation Fault steam generation
	dark bright flashes	Main contactor switched Main contactor not switched Fault main contactor
	dark bright flashes	Filling active No filling Fault filling
	dark bright flashes	Blow-down active No blow-down Fault blow-down <u>Manual blow-down</u> A manual blow-down can be triggered by touching the icon. Touching the icon again stops the manual blow-down. Max. blow-down time corresponds to the parameter setting for full blow-down
	dark bright flashes	Demand has been made Demand has been made Fault demand
	dark bright	Interlock (safety) system closed Interlock (safety) system open
	dark bright	Virtual interlock (safety) system closed (via communication interface) Virtual interlock (safety) system open
	dark flashes	Operating mode display Unit is in the initialisation phase

5. Operation of control

5.1 Operation basics



Operation takes place via the built-in touch-sensitive 3.5 inch screen. It is used for all operating steps required for the settings and operation of the unit. In addition to operating the unit directly, it is possible to control it remotely via the building technology control system or a PLC, using the communication interface. Supplementary documentation is available from HygroMatik for this type of application.






Screen views

The operating structure uses several screens, which are schematically displayed in the table below.

User guidance

In the user guidance, a distinction is made between the "user level" and "operator level". While the user level only makes it possible to carry out basic device operations, the operator level also permits operating parameters to be changed. The 2nd table below clarifies this again. The possible operating functions of the two levels are presented in Sections 5.5 and 5.7.

Overview of the screens

	Content of screen page	Presentation	Sec.
Screen 1 Initial operation	Used for the basic unit settings (e.g. user language) after the unit is switched on for the first time. This page is then closed. To do so, use the confirmation tick to exit it.		5.3
Screen 2 Main screen	Displays the current operating values and unit status information (status icons).		5.4
View 3 Main menu (user level)	Allows access to submenus for limited unit settings, read values and history		5.5
View 3 Main menu (operator level)	Allows access to submenus for comprehensive unit settings, read values, parameter settings, service settings and history		5.7
Screen 4 Unit information	Is only displayed after a fault or a service message has occurred; provides information on device data, statistics, faults that have occurred and service requirements.		5.9

Operating ranges at the user/operator level

Level	Permits
User level	<ul style="list-style-type: none"> • Display of the read values of the main screen • Setting the humidity set value in the main screen • Display of the unit information after a fault or status message • After entering the password - call-up and cancellation: Display of the complete list of read values and adjustment options for some service parameters
Operator level	<ul style="list-style-type: none"> • All functions of the user level • Advanced settings options for operation and service parameters

5.2 Screen 1 - Commissioning

After connection to the mains supply and initial actuation of the control switch, the commissioning screen for the basic device settings appears on the display once the self-test of the control has been completed:

X	01: Commissioning	✓
01: Language	English	
02: Date	31/10/2017	
03: Time	11:59	
04: Control	User-defined	

5.2.1 Setting the language

- » Touch the line with parameter "01: Language". The following screen is displayed:

<	Language	✓
German		
English		✓
Français		
Castellano		▼

- x The currently selected language is marked with a tick in the relevant line. With the scroll-down button, the 2nd page of the screen is displayed if required
- » Change the language by touching it, if required

- » Confirm the input and return to the "Initial operation" screen with the green tick in the top right (cancel by touching "X")

5.2.2 Input of date and time

The parameter "02: Date" and "03: Time" require digits to be entered. To do so, a screen with a keyboard and an input field in the date or time format will be displayed after touching the relevant line.

As an example, the date input is described below:

- » Touch line "02: Date". The following screen is displayed:


X	Date			✓			
28.10.17							
					1	2	3
					4	5	6
					7	8	9
	.	0	⬅ X				

- » Enter the date in the format DD.MM.YY (D = day, M = month, Y= year) as digits only (the dots are added automatically)
- » Confirm the input and return to the "Initial operation" screen with the green tick in the top right (cancel by touching "X")

5.2.3 Control settings

The type of unit control is specified in the next step. The screen offers the most commonly used combinations of the operating mode of the control (1 step, controlled with an external regulator, with the internal PI controller, via the communication interface, slave operation), the type of control signal (voltage, current or resistance signal) and the control signal range (e.g. 0... 10 V). If these values have already been factory-preset according to customer requirements, the selection tick appears in the "User-defined" line.

The parameters are displayed in blocks on a screen page, which include a maximum of 4 entries. Scroll keys are used to switch between the individual screen blocks.




The initial operation is now complete. If the initial operation screen was exited with the confirmation tick, the main screen is automatically shown in the display. The initial operation screen is no longer displayed in future. Future changes with respect to the parameters set during initial operation must be made on operator level in submenus „Settings“ and „Control“.

- » Confirm the input and return to the "Initial operation" screen with the green tick in the top right (cancel by touching "X")
- » Pressing the green tick in the top right saves the entries and exits the initial operation screen (cancel by pressing the "X")

5.2.4 Line-up of the initial operation parameters



No. Parameter	Adjustment/value range Factory presets (FP) bold	Meaning/comment [] explains the term in the glossary → [] refers to a related term explanation
01 Language	No. Selection	Selection of language
	0 Deutsch	German
	1 English	English
	2 Francais	French
	3 Castellano	Spanish
	4 ニホンゴ	Japanese
	5 Italiano	Italian
	6 Русский	Russian
02 Date		Date setting in DD.MM.YYYY format
03 Time_of_day		Clock setting in HH:MM format
04 Control_setting	No. Selection	Clock setting in HH:MM format
	0 User_specified	The selection was carried out separately during initial operation according to control type, signal type and area. This is a read value only
	1 Extern_0...10 V	External controller [73] with voltage signal 0... 10 V
	2 Extern_0...20 mA	External controller [73] with current signal 0... 20 mA
	3 Extern_0...140 Ω	External controller [73] with ohmic signal 0...140 Ω
	4 PI controller_0...10 V	Internal PI controller [96], controls with voltage signal 0...10 V
	5 PI controller_4...20 mA	Internal PI controller [96], controls with current signal 4... 20 mA
	6 PI controller_0...140 Ω	Internal PI controller [96], controls with ohmic signal 0...140 Ω
	7 1-step	1 step operation [44]
	8 Modbus	Control via software control commands [12] through communication interface [13]
	11 PI controller_V_max_mA	Selection of current input on the mainboard for the 2nd PI controller when using the floating max. limiter [35]
	12 PI controller_V_max_V	Selection of voltage input on the 1st relay board for the 2nd PI controller when using the floating ma. limiter [35]

5.3 Screen 2 - Main screen



The main screen is shown in the display after the unit is switched on, unless the unit is being switched on for initial operation (see Section "Initial operation"). In the main screen, current operating values are represented as numerical information, as well as status information in the form of icons. The display elements were described in Section 4 "The screen". A flashing icon always indicates a fault.

The left row of icons refers to the operational conditions of the unit. The right row of icons indicates the status of releases. For steam production to take place, all icons on the right side of the screen must be active.

The scroll keys  and  allow the user to move through the list of display values on the main screen (see Section 4, "The screen"). With the exception of the target humidity, these are read values only. The displayed values are shown and explained in the table in the following section.

If an error has occurred or a service message is issued, a display field with the relevant message is displayed instead of the Hygro-Matik logo. The user can access the unit info screen by touching this field.

The brightness of the main screen is reduced after a certain time (screen brightness is dimmed). The two scroll keys and the settings icon are also hidden at this point. The original state is restored by touching the screen.

The values for the normal display brightness

and the dimmed state can be adjusted by the user, as well as the duration after which the main screen is changed to the dimmed state.


The main menu of the user level and the operator level (screen 3) is accessed by touching the  icon. List of read values and target humidity of the main screen

Table of the read values available in the main screen and the humidity set value


No. Parameter	No.	Adjustment/value range			Meaning/comment [] explains the term in the glossary → [] refers to a related term explanation
		min	max	FP	
1 Humidity_actual_value		Reading value			The actual value [1] of the humidity [2] in % RH (only if PI controller is selected)
2 Humidity_set_value		0	100,0	50,0	The target value [3] of the humidity [2] in % RH (only if PI controller is selected). Tapping the display value opens a virtual keyboard, which is used to change the target value. For information on how to operate the keyboard, see section "Input of date and time".
7 Steam_actual_unit		Reading value			The current steam output [4] in kg/h
9 Steam_output_max.		Reading value			The set value of the maximum steam output [43] as a percentage of the nominal output [99]
10 Demand		Reading value			The current request [5] as a percentage of the maximum level
11 Control_sig_internal		Reading value			The internal actuator signal [42] controls the power element [100] of the unit
12 Output_signal		Reading value			The output signal [69] can be used to control additional units
13 Current_actual_cyl. 1		Reading value			The current amperage (only for ELDB [77])
14 Current_actual_cyl. 2		Reading value			The current amperage (only for ELDB [77] double cylinder units)
15 Water_level_cyl. 1		Reading value			The water level in level control in mm (only for HKDB [78])
16 Water_level_cyl. 2		Reading value			The water level in level control in mm (only for HKDN [78] double cylinder units)
20 Humidity_actual_max		Reading value			The actual value [1] of the RH [2] in the range of 2nd humidity sensor if the floating max. limiter [35] was selected
21 Humidity_set_max		Reading value			The target value [3] of the RH [2] in the range of 2nd humidity sensor if the floating max. limiter [35] was selected

5.4 Password entry

The password determines if the main menu of the user level or the operator level is displayed. The password codes in use are:

Code 000: The main menu of the user level becomes accessible. However, it is sufficient to leave the password prompt with the green tick, without explicitly entering the code.

Code 010: The main menu of the operator level becomes accessible.


The password entry is called up in the main screen by touching the  button. A virtual keyboard is shown on the screen for entering the password:






To open the user level, it is sufficient to select the X symbol (top left). The operator level is accessed through the sequential input of the code digits "0", "1" and "0" and confirming them with the green tick (top right).

5.5 Screen 3 - Main menu (user level)

After selecting the user level, the icons of the submenus which are available to the user are displayed:



5.6 User level submenus

Icon	Selection of submenu
	Settings
	Read values
	History

By tapping on the respective icon, the user accesses the screen page where the parameters of the respective group are displayed for selection, viewing or for making changes.

Layout of screen page

The input fields in which changes can be made are shown in *italics*. Depending on the parameter, the input has to be made by:

- selection from predefined offers (multiple choice, see example 1)
- entry of numeric values using an on-screen keyboard (see example 2).

Example 1: Selection of user language:

Call up the language selection on the screen by touching "Language:




By tapping on the required language, the black tick moves to the corresponding row. By touching the green tick (top right), the selection is saved and the display returns to the parent screen.

If the settings are to remain unchanged, it is possible to return straight away using the < key.

Example 2: Setting the screen brightness

Touch "Screen_brightness normal" on the screen to call up the input mask:



The screen brightness which is set is displayed and can be changed by using the keyboard. Save and return by touching the green tick, leave the input mask without changes by touching the "X".

The screens are hidden after a certain period of time. The main screen is then displayed. The time until the return to the main screen can be set by the user.

If a submenu is to be called up again after a screen has been closed automatically by a time-out, this can only be done through the settings icon in the main screen. This also means that the password has to be re-entered. As long as the user continues their work in the area of the main screen, the existing access remains, i.e. no renewed password entry is required.

5.6.1 Settings submenu



Table of settings parameters

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold			Meaning/comment [] explains the term in the glossary →[] refers to a related term explanation
1	Language		Selection			Language selection
		0	Deutsch			German
		1	English			English
		2	Francais			French
		3	Castellano			Spanish
		4	日本語			Japanese
		5	Italiano			Italian
		6	Русский			Russian
2	Date		DD/MM/YY			Set date
3	Time_of_day		HH:MM			Set time
			min	max	FP	
4	Display_lighting_normal		0	100	100	Screen backlight in undimmed state
5	Delay_present_page		0	3600	300	display duration for a certain screen page before return to the main screen in min
6	Display_lighting_dimmed		0	100	50	Screen brightness for dimmed state
7	Display_dim_after		0	3600	120	Switching of screen brightness of main screen to dimmed value after ... seconds. If an error has occurred or a status message is displayed, the main screen is not dimmed

5.6.2 Read values submenu



Read values table (visible on the user and the operator level)

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold min max FP	Meaning/comment [] explains the term in the glossary →[] refers to a related term explanation
1	Status_unit			Operating condition of unit
		0	Initialization	Control performs initialisation [10]
		1	Safety_interlock_open	Unit is ready for steam production, but the interlock (safetF) system [11] is open
		2	No_Demand	Unit is ready for steam production, but there is no request [5]
		3	Humidification	Humidifying [47]
		4	Runtime_limitation	Unit has switched off after limitation of operating time was reached [32]
		5	Remote_off	Unit was switched off via a software command [12] for opening the interlock (safety) system [83] via the communication interface [13]
		7	Standby_heating_heating	The standby heating [16] is in the heating phase
		8	Standby_heating_interval	The standby heating [16] is in the resting phase
		9	No_demand_ECO	There is no request [5] in ECO mode [17]
		10	Humidification_ECO	Humidifying in ECO mode [17]
		11	Timer_steam_off	Steam is not produced after the timer [18] has expired
		90	Diagnosis	Unit is performing diagnostics [15]
		99	Fault	An error has occurred; steam production was stopped
2	Status_cyl. 1			Status of cylinder 1
		0	Initialization	Unit is in initialization phase →[10]
		1	Safety_interlock_open	Cyl. 1 is ready for steam production, but the interlock (safety) system [11] is open
		2	No_Demand	Cyl. 1 is ready for steam production, but there is no request [5]
		3	Humidification	Humidifying [47]
		30	Filling_valve 1	Filling via SV1 [19]
		32	Filling_valve 1 a. 2	Filling via SV1 and SV2 [19]
		60	Start_blow-down	At the start of operation, the unit performs a start blow-down [20]
		61	Part_blow-down	A partial blow-down [21] is performed
		62	Full_blow-down	A full blow-down [22] is performed
		63	Dilution	The unit performs a dilution [23] of the cylinder water (only ELDB [77])
		64	Max._current_blow-down	The unit performs an overcurrent blow-down [24] because the measured current is too high (only for ELDB [77])
		65	Max._level_blow-down	The unit performs a max. level blow-down [25] because the water level is too high (only for HKDB [78])
		66	Standby_blow-down	The unit performs a Standby blow-down [26], because the maximum duration without request [5] has been reached
		67	Dead_leg_flushing	A dead-end line flushing is performed [27]
		68	Manual_blow-down	A manual blow-down [28] is triggered
		81	Part_blow-down_pending	A partial blow-down [21] is performed before the next filling process
		82	Full_blow-down_pending	A full blow-down [22] is performed before the next filling process
		90	Cylinder_full	The sensor electrode reports when the maximum water level in the cylinder has been reached (only for ELDB [77])
		270	Service_message	A service message is present. For a more detailed specification see "Read values 7" for cyl. 1 or "Read values 8" for cyl. 2
		900	Diagnosis	The unit is in diagnostic mode [15]
		999	Fault	There is an error
3	Status_cyl. 2			Status of cylinder 2 (as cylinder 1)
4	Fault_message_unit			List of possible unit error messages
		0	No_fault	No fault
		1	Plug_ST09	The plug for the current transformer (ELDB) or the level control (HKDB) is not attached
		2	Cylinder_extension 1	There is a problem with the expansion board
		6	Relay_extension 1	There is a problem with relaF board 1
		7	Relay_extension 2	There is a problem with relaF board 2
		24	Input_resistance_OC	Minimum value of resistance input/NTC input not plausible
		25	Input_resistance_SC	Maximum value of resistance input/NTC input not plausible
		29	Internal	system error
		30	Filling_valve 1	Error SV1 [19]
		32	Filling_valve 1 a. 2	Error SV1 and SV2 [19]
		61	Part_blow-down	Partial blow-down [21] not successful
		62	Full_blow-down	Full blow-down [22] not successful
		63	Blow-down_dilution	Dilution [23] was not successful (only for ELDB [77])
		64	Max._current_blow-down	Overcurrent blow-down [24] was not successful (only for ELDB [77])
		65	Max._level_blow-down	Max. level blow-down [25] was not successful (only for HKDB [78])
		66	Standby_blow-down	Stand-by blow-down [26] not successful
		67	Start_blow-down	Start blow-down [20] not successful

Read value table (ctd.) (1)

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold min max FP	Meaning/comment [] explains the term in the glossary → [] refers to a related term explanation
		90	Cylinder_full	Sensor electrode reports cylinder full status [38] for 60 min (only for ELDB [77])
		91	Current_measurement	Value provided bF current measurement not plausible (only for ELDB [77])
		92	Main_contactor_current	A current is measured for at least 15 s, even though the main contactor [72] is not actuated (only for ELDB [77])
		93	Main_contactor_cyl._full	A cylinder full status [38] was detected for at least 15 s, even though the main contactor [72] is not actuated (only for ELDB [77])
		120	Thermoswitch	A thermo sensor [31] has been triggered (only for HKDB [78])
		121	Water_level_sensor	Value provided by level control [39] not plausible (only for HKDB [78])
		122	Max.-level	Max. level [40] was reached 5 times in a row during filling (only for HKDB [78])
		123	Steam_down_time	Despite a current feed to the radiators, the water level has not changed in the period specified →[53] (only for HKDB [78])
		124	Relay_main_contactor	The relay for the control of the main contactor is not functioning correctly
		210	Humidity_sensor	Humidity sensor, cable or input level defective
5	Fault_message_cyl. 1			List of possible fault messages for cylinder 1 (see Unit error)
6	Fault_message_cyl. 2			List of possible fault messages for cylinder 2 (see Unit error)
		7	Operating_time	The number of operating hours preset has been reached
8	Service_message_cyl. 1			List of service messages for cylinder 1
		0	No_service_msg.	A service is not required
		1	Steam_amount_counter	A unit service is required due to the steam volume counter
		2	Cycles_main_contactor 1	The maximum number of operating cycles for K1 has been reached and a Service_main_contactor [34] is required
		3	Cycles_main_contactor 2	The maximum number of operating cycles for K2 has been reached and a Service_main_contactor [34] is required
		12	Warning_electrodes	The condition of the electrodes will require a replacement shortly (only for ELDB [77]) →[95]
		13	Warning_pump	In the area of the blow-down pump and/or the piping, there are indications that maintenance requirements are starting to develop →[95]
		14	Warning_solenoid_valve	At a solenoid valve and/or the piping, there are indications that maintenance requirements are starting to develop →[95]
9	Service_message_cyl. 2			List of service messages for cylinder 2
		0	No_service_msg.	A service is not required
		1	Steam_amount_counter	A unit service is required due to the steam volume counter
		4	Cycles_main_contactor 3	The maximum number of operating cycles for K3 has been reached and a Service_main_contactor [34] is required
		5	Cycles_main_contactor 4	The maximum number of operating cycles for K4 has been reached and a Service_main_contactor [34] is required
		6	Cycles_main_contactor 5	The maximum number of operating cycles for K5 has been reached and a Service_main_contactor [34] is required
		12	Warning_electrodes	The condition of the electrodes will require a replacement shortly (only for ELDB [77]) →[95]
		13	Warning_pump	In the area of the blow-down pump and/or the piping, there are indications that maintenance requirements are starting to develop →[95]
		14	Warning_solenoid_valve	At a solenoid valve and/or the piping, there are indications that maintenance requirements are starting to develop →[95]
10	Steam_actual_unit		Reading value	Current steam output of the unit [4]
11	Steam_actual_cyl. 1		Reading value	Current steam output [4] of cylinder 1 (for double cylinder units)
12	Steam_actual_cyl. 2		Reading value	Current steam output [4] of cylinder 2 (for double cylinder units)
16	Steam_output_max.		Reading value	Set value of maximum output power [43]
17	Demand		Reading value	The demand [5] is the control signal from which the internal actuator signal [42] is created
18	Control_sig_internal		Reading value	Internal actuator signal [42] as a percentage of the actuator signal for the nominal output
19	Output_signal		Reading value	Output signal [69] on terminals 12, 13 proportional to input signal
20	Safety_interlock			Status of the interlock (Safety) system [11]
		0	Off	The interlock (safety) system is open
		1	On	The interlock (safety) system is closed
21	Safety_interlock_virtual			Status of the virtual interlock (safety) system [86]
		0	Off	The interlock (safety) system is open
		1	On	The interlock (safety) system is closed

Read value table (ctd.) (2)

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold min max FP	Meaning/comment [] explains the term in the glossary → [] refers to a related term explanation
22	Current_actual_cyl. 1		Reading value	The current power consumption of cylinder 1 (only for ELDB [77])
23	Current_actual_cyl. 2		Reading value	The current power consumption of cylinder 2 (only for ELDB [77] double cylinder units)
24	Water_level_cyl. 1		Reading value	Water level in cylinder 1 in mm (only for HKDB [78])
25	Water_level_cyl. 2		Reading value	Water level in cylinder 2 in mm (only for HKDB [78] double cylinder units)
28	Model		Reading value	Type designation of unit
29	Unit_name		Reading value	Unit name [90], can be selected by the customer, if required
30	Serial_number		Reading value	Serial number
31	Date_of_manufacturing		Reading value	Date of manufacture
32	Controller_series		Reading value	Type of control
33	Software_version		Reading value	Software version of control
34	Humidity_set_value		Reading value	Set value [3] of rel. humidity [2] in %
35	Humidity_actual_value		Reading value	Actual value [1] of rel. humidity [2] in %
46	Steam_amount_total_cyl. 1		Reading value	Entire steam volume of cylinder 1 [kg] produced since initial operation
47	Steam_amount_total_cyl. 2		Reading value	Entire steam volume of cylinder 2 [kg] produced since initial operation (double cylinder units only)

5.6.3 History submenu



This submenu is identical on the user and the operator level.

5.6.3.1 Explanation of history management

The control stores 10 sets of error messages on a rolling basis. Once there are 10 records, the oldest record is overwritten by a current entry. An error message set consists of the following entries:

1. Date of error message
2. Contents of error message
3. Frequency of error message

If an identical error occurs several times in a row, the first entry relating to this error is updated with the date of the most recent occurrence and the frequency is incremented. A new error message set is not recorded.

The situation is different if a particular error occurs multiple times, but not in direct succession. In this case, a new error message set is written for each instance.

The table below shows the layout of the history management.

Table of history layout

No. Parameter	No.	Adjustment/value range Factory presets (FP) bold	Meaning/comment
1 1st fault_entry_date			1. Memory entry: Date/time
2 1st fault_entry_message			1. Memory entry: Error message (for explanation see "Read values 4 / error message")
	0	No_fault	
	1	Plug_ST09	
	2	Cylinder_extension 1	
	6	Relay_extension 1	
	7	Relay_extension 2	
	24	Input_resistance_OC	
	25	Input_resistance_SC	
	29	Internal	
	30	Filling_valve 1	
	32	Filling_valve 1 a. 2	
	61	Part_blow-down	
	62	Full_blow-down	
	63	Blow-down_dilution	
	64	Max._current_blow-down	
	65	Max._level_blow-down	
	66	Standby_blow-down	
	67	Start_blow-down	
	90	Cylinder_full	
	91	Current_measurement	
	92	Main_contactor_current	
	93	Main_contactor_cyl._full	
	120	Thermoswitch	
	121	Water_level_sensor	
	122	Max.-level	
	123	Steam_down_time	
	124	Relay_main_contactor	
	210	Humidity_sensor	
3 1st fault_entry_rate			1. Memory entry: Frequency of occurrence (since initial operation)
4 2nd fault_entry_date			2. Memory entry: Date/time
5 2nd fault_entry_message			2. Memory entry: Error message, see above
6 2nd fault_entry_rate			2. Memory entry: Frequency of occurrence (since initial operation)
7 3rd fault_entry_date			3. Memory entry: Date/time
8 3rd fault_entry_message			3. Memory entry: Error message see above
9 3rd fault_entry_rate			3. Memory entry: Frequency of occurrence (since initial operation)
10 4th fault_entry_date			4. Memory entry: Date/time
11 4th fault_entry_message			4. Memory entry: Error message see above
12 4th fault_entry_rate			4. Memory entry: Frequency of occurrence (since initial operation)
13 5th fault_entry_date			5. Memory entry: Date/time
14 5th fault_entry_message			5. Memory entry: Error message see above
15 5th fault_entry_rate			5. Memory entry: Frequency of occurrence (since initial operation)
16 6th fault_entry_date			6. Memory entry: Date/time
17 6th fault_entry_message			6. Memory entry: Error message see above
18 6th fault_entry_rate			6. Memory entry: Frequency of occurrence (since initial operation)
19 7th fault_entry_date			7. Memory entry: Date/time
20 7th fault_entry_message			7. Memory entry: Error message see above
21 7th fault_entry_rate			7. Memory entry: Frequency of occurrence (since initial operation)
22 8th fault_entry_date			8. Memory entry: Date/time
23 8th fault_entry_message			8. Memory entry: Error message see above
24 8th fault_entry_rate			8. Memory entry: Frequency of occurrence (since initial operation)


Continuation of history layout

No. Parameter	No.	Adjustment/value range Factory presets (FP) bold	Meaning/comment
25 9th fault_entry_date			9. Memory entry: Date/time
26 9th fault_entry_message			9. Memory entry: Error message see above
27 9th fault_entry_rate			9. Memory entry: Frequency of occurrence (since initial operation)
28 10th fault_entry_date			10. Memory entry: Date/time
29 10th fault_entry_message			10. Memory entry: Error message see above
30 10th fault_entry_rate			10. Memory entry: Frequency of occurrence (since initial operation)


5.7 Screen 3 - Main menu (operator level)

After the operator level has been selected by entering the corresponding password (code 010), the main menu is displayed. It spans multiple screen pages and scroll keys are used to navigate between them.


Screen page 1 (of 3)



Screen page 2



Screen page 3



5.8 Operator level submenus

By touching the respective icon, the operator accesses the screen page where the parameters of the respective group are available for selection, viewing or for making changes. The layout of the screen pages corresponds to the pages of the submenus of the user level (see Section 5.7).

Icon	Selection of submenu
	Settings
	Read values
	Control
	Service
	Archive
	Blow-down
	Filling
	Functions
	Communication interface
	Timer
	Recording
	Relay expansion 1 (visible only if a relay board is present)
	Relay expansion 2 (visible only if 2nd relay board is present)

The parameters available in the submenus are described in table form below (for explanations on the individual parameters see Glossary in Section 8).

5.8.1 Settings submenu



Table of settings parameters (operator level)

No. Parameter	No.	Adjustment/value range Factory presets (FP) bold	Meaning/comment [] explains the term in the glossary →[] refers to a related term explanation
1 Language		Selection	Language selection
	0	Deutsch	German
	1	English	English
	2	Francais	French
	3	Castellano	Spanish
	4	日本語	Japanese
	5	Italiano	Italian
	6	Русский	Russian
2 Date		DD/MM/YY	Set date
3 Time_of_day		HH:MM	Set time
		min max FP	
4 Display_lighting_normal		0 100 100	Screen backlight in undimmed state
5 Delay_present_page		0 3600 300	display duration for a certain screen page before return to the main screen in min
6 Display_lighting_dimmed		0 100 50	Screen brightness for dimmed state
7 Display_dim_after		0 3600 120	Switching of screen brightness of main screen to dimmed value after ... seconds. If an error has occurred or a status message is displayed, the main screen is not dimmed
8 Units			Selection of system of units
	0	SI	Units are displayed in the format of the SI system of units [8]
	1	Imperial	Units are displayed in the format of the imperial system of units [9]

5.8.2 Read values submenu



The read value submenu is no different to that of the user level. The read values listed in table format in Section 5.6. are also available at the operator level.

5.8.3 Control submenu



Table of control parameters

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold			Meaning/comment [] explains the term in the glossary →[] refers to a related term explanation
1	Control_settings					Combinations of control type and input signal type/range
		0	User_specified			The selection was carried out separately during initial operation according to control type, signal type and area. This is a read value only
		1	Extern_0...10 V			External controller [73] with voltage signal 0... 10 V
		2	Extern_0...20 mA			External controller [73] with current signal 0... 20 mA
		3	Extern_0...140 ?			External controller [73] with ohmic signal 0...140 Ω
		4	PI controller_0...10 V			Internal PI controller [96], controls with voltage signal 0...10 V
		5	PI controller_4...20 mA			Internal PI controller [96], controls with current signal 4... 20 mA
		6	PI controller_0...140 Ω			Internal PI controller [96], controls with ohmic signal 0...140 Ω
		7	1-step			1 step operation [44]
		8	Modbus			Control via software control commands [12] through communication interface [13]
		9	Slave			Unit operates as slave [94] in a master/slave unit network
		10	PI controller			Control with internal PI controller [96]
		11	PI controller_V_max_mA			Selection of power input on the mainboard for the 2nd PI controller when using the floating max. limiter [35]
		12	PI controller_V_max_V			Selection of voltage input on the 1st relay board for the 2nd PI controller when using the floating max. limiter [35]
			min	max	FP	
2	Steam_output_max.		25,0	100,0	100	The maximum output power [43] can be limited to between 25 and 100%
3	Δ Power_reduction		0	50,0	0	Reduction of the maximum steam output for the purpose of load shedding [101]
4	Output_signal					Mapping of the output signal [69] to an internal value
		0	Off			No mapping
		1	Control_sig_external			Output signal is proportional to the request [5] from the external controller [73]
		2	Control_sig_internal			Output signal is proportional to the internal actuator signal [42]
		3	Humidity_actual_value			Output signal is proportional to the actual humidity value [1]
		4	Control_signal_slave			Output is used to control a slave [94]
			min	max	FP	
17	Humidity_set_value		0	100,0	50,0	Set value [3] of RH [2] in %
18	Δ Set_value_dehumidification		1,0	20,0	10,0	Downstream dehumidifier is actuated if humidity set value has been exceeded by the respective difference value [%], (PI controller only), → [50]
19	Δ Humidity_ECO		0	50,0	10,0	Target humidity is lowered by this percentage when ECO is switched on
20	PI-controller_gain		0,5	100,0	5,0	Proportional part of PI controller
21	PI-controller_integral		0	100	10	Integral part of PI controller
22	Humidity_notification		5,0	99,9	50,0	When the set humidity [%] has been reached, one of the relays is energised, which must have been assigned code "211" (humidity reached) for this purpose
23	Humidity_set_max		0,0	99,9	80,0	Specification of max. humidity for the switch-off point when using the floating max. limiter [35]
24	PI-controller_max_gain		0,5	100,0	5,0	Amplification of 2nd PI controller when using the floating max. limiter [35]

5.8.4 Service submenu



5.8.4.1 Monitoring and service messages

The wear components of the unit and the status of the steam cylinder(s) are monitored continuously when the unit is in operation. When a limit value is reached, the corresponding service message is displayed with reference to the cylinder. The service messages need to be reset after component replacement or cylinder maintenance.

The following service messages are implemented:

Steam volume

A steam volume in kg is specified in the "Steam_volume_service" parameter and after this is reached, the message "Steam volume counter" is issued. In case of double cylinder units, the parameter entry applies to both cylinders. The service message differentiates between cylinder 1 and cylinder 2.

After the service has been carried out, the message has to be reset with "Reset_cyl. 1" or "Reset_cyl. 2" (or both).

For the assessment of the remaining steam volume until the next service is required, the read values "Steam_volume_to_service_cyl. 1" and "Steam_volume_to_service_cyl. 2" (only for double cylinder units) are used.

Main contactors

For main contactors, the maximum number of operating cycles is specified by the manufacturer. When a limit value is reached, the corresponding service message is displayed. The main contactor must then be changed and the message has to be reset by setting the "Main_contactor Kx_Reset" (x = 1...5) parameter.

Please note

When the service message was triggered for one of the main contactors, it is advisable to check the meter reading for the remaining main contactors.

Monitoring

The FlexLine control permanently monitors the performance capabilities of the electrodes (ELDB only), of the blow-down pump(s), and of the solenoid valve(s). When preset functionality warning thresholds are exceeded, messages are generated with respect to the current state of:

- Electrodes (ELDB only), („Warning_cyl._full“)
- Blow-down pump(s) („Warning_pump“)
- Solenoid valve(s) („Warning_valve“)

Three sensitivity values can be selected for each of the alarm thresholds, where "Sensitivity 3" triggers the warning messages at the earliest time. The highest sensitivity threshold is set ex-factory.

After the condition for triggering the warning has been resolved (e.g. by cleaning the solenoid valve intake strainer), no further warning is issued. The warning messages can also be turned off (s. parameters 22, 23 and 24 in the table following hereunder).

Table of service parameters

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold	Meaning/comment [] explains the term in the glossary → [] refers to a related term explanation
1	Steam_amount_service			Preset steam volume (see [33]) in kg until service message is triggered. For double cylinder units, this setting applies to both cylinders
4	Service-reset_cyl. 1			Reset steam volume counter for cylinder 1 → [33]
		0	Off	No
		1	On	Yes
5	Steam_until_msg_cyl. 1			Remaining steam volume for cyl. 1 until service message → [33] is triggered
7	Service-reset_cyl. 2			Reset steam volume counter for cylinder 2 → [33], double cylinder units only
		0	Off	No
		1	On	Yes
8	Steam_until_msg_cyl. 2			Remaining steam volume for cyl. 2 until service message → [33] is triggered
12	Main_contactor 1_reset			Reset K1 counter for main contactor operating cycles? → [34]
		0	Off	No
		1	On	Yes
13	K1_switching_cycles_until_msg.			Remaining operating cycles for K1 until service message → [34] is triggered
14	Main_contactor 2_reset			Reset K2 counter for main contactor operating cycles? → [34]
		0	Off	No
		1	On	Yes
15	K2_switching_cycles_until_msg.			Remaining operating cycles for K2 until service message → [34] is triggered
16	Main_contactor 3_reset			Reset K3 counter for. main contactor operating cycles? → [34] (double cyl. units only)
		0	Off	No
		1	On	Yes
17	K3_switching_cycles_until_msg.			Remaining operating cycles for K3 until service message → [34] is triggered
18	Main_contactor 4_reset			Reset K4 counter for main contactor operating cycles? → [34] (double cyl. units only)
		0	Off	No
		1	On	Yes
19	K4_switching_cycles_until_msg.			Remaining operating cycles for K4 until service message → [34] is triggered
20	Main_contactor 5_reset			Reset K5 counter for main contactor operating cycles? → [34] (double cyl. units only)
		0	Off	No
		1	On	Yes
21	K5_switching_cycles_until_msg.			Remaining operating cycles for K5 until service message → [34] is triggered
22	Warning_cyl_full			Warning message about electrode burn-off (only for ELDB [77]) → [95]
		0	Off	No message
		1	Sensitivity 1	Threshold value 1 for message (lowest sensitivity)
		2	Sensitivity 2	Threshold value 2 for message (medium sensitivity)
		3	Sensitivity 3	Threshold value 3 for message (highest sensitivity)
23	Warning_pump			Warning message about functional performance of blow-down pump → [95]
		0	Off	No message
		1	Sensitivity 1	Threshold value 1 for message (lowest sensitivity)
		2	Sensitivity 2	Threshold value 2 for message (medium sensitivity)
		3	Sensitivity 3	Threshold value 3 for message (highest sensitivity)
24	Warning_valve			Warning message about functional performance of solenoid valves → [95]
		0	Off	No message
		1	Sensitivity 1	Threshold value 1 for message (lowest sensitivity)
		2	Sensitivity 2	Threshold value 2 for message (medium sensitivity)
		3	Sensitivity 3	Threshold value 3 for message (highest sensitivity)
26	Update_function			Status of update function [7]
		0	USB-stick_insert	USB stick is not inserted
		1	Loading	The parameter set which is saved on the stick is loaded
		2	Checking	The loaded parameter set is checked
		3	Update	The parameter set is updated
		4	Successful	The update was successful
		5		USB stick does not contain a parameter set or parameter set is not compatible
31	Main_relay_on/off			Targeted function test
		0	Off	
		1	On	

5.8.4.2 Procedure for parameter update

The information below explains how to work with the "Update_function" parameter (see parameter row 26 in the table above).

The update function makes it possible to overwrite parameter settings with a parameter set which is saved on an external USB flash drive. As a result, the operator can make a change without having to change the parameters by themselves. The modified parameter set can be provided by HygroMatik.

The procedure is as follows:


- » With the unit switched on, insert the USB stick into the socket on the mainboard.
- » Call up the "Update function" in the services submenu.

The status of the update process is displayed (see table). Its successful completion is displayed by the "Update successful" status message.

- » Switch the unit off and on again. The loaded parameter set is activated.
- » To reload the parameter set at a later date if required (e.g. after a factory reset), the "ImportDone.txt" file on your USB stick must be deleted beforehand. To do so, the stick must be inserted in an external device (e.g. PC).

If the status "Invalid data" is output after the update operation, a compatible parameter set is not available on the USB stick.

USB connector on mainboard



5.8.5 History submenu



The error message history was already described for the user level in Section 5.6.3. There are no differences at the operator level.

5.8.6 Blow-down submenu



Table of blow-down parameters

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold min max FP			Meaning/comment [] explains the term in the glossary → [] refers to a related term explanation
1	Full_blow-down_correction		-5	5	0	Correction value for frequency of full blow-down ("+" = more frequently, "-" = less frequently) → [55]
2	Part_blow-down_correction		-5	5	0	Correction value for frequency of partial blow-down ("+" = more frequently, "-" = less frequently) → [55]
3	Standby_blow-down					Full blow-down [58] for hygiene reasons, if there was no steam production → [26] for an extended period
		0			Off	No stand-by blow-down
		1			On	Blow-down after waiting period
4	Standby_blow-down_interval					After the waiting period specified, the remaining water is pumped off if the interlock (safety) system [11] was opened during this period of time, i.e. no steam production took place → [26]
5	Blow-down_without_K1					Pumps without main contactor [75] in order to avoid triggering of residual current detector → [56]
		0			Off	Main contactor [75] switched on during pumping
		1			On	Main contactor [75] switched off during pumping

5.8.7 Fill parameters submenu



Table of fill parameters

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold min max FP			Meaning/comment [] explains the term in the glossary → [] refers to a related term explanation
1	Filling_pulsed					The filling process is not continuous, but intermittent → [54]
		0			Off	Activated
		1			On	Not activated
2	Filling_pulsed_interval		1	10	2	Time interval in s, during which filling does not take place (filling pause)
3	Filling_pulsed_active		1	600	10	Duration of filling time in s until filling pause

5.8.8 Functions submenu



Table of function parameters

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold min max FP	Meaning/comment [] explains the term in the glossary →[] refers to a related term explanation
1	Standby-heating			The standby heating [16] keeps the water in the cylinder warm if no request [5] is present
		0	Off	Standby heating [16] switched off
		1	On	Standby heating [16] switched on
2	Standby-heating_interval			Pause time of standby heating in [min]
3	Standby-heating_active			Heating time of standby heating [16] in [s]
4	Dead_leg_flushing			The solenoid valves of the water input and blow-down pump are switched on and off simultaneously with the flushing of the dead-end line [27]
		0	Deactivated	Flushing of dead-end line [27] is not carried out
		1	Activated	Facilitate flushing of dead-end line [27]
5	Dead_leg_flushing_interval			Waiting period until start of flushing of dead-end line [27] in [min]
6	Dead_leg_flushing_active			Duration of flushing of dead-end line [27] in [s]
7	Runtime_limitation			Steam production is stopped after the time interval specified [min]
8	Weekly_timer			Activation of weekly timer
				Steam production runs continuously with the parameters preset
				Steam production is only active in time periods preset in the "Weekly timer" submenu
9	Timer_mode			The timer function [18] is triggered with an external button
		0	Off	The timer function [18] is not available
		1	Steam_off	Steam production stops after the timer has elapsed
		2	ECO	The unit reverts to ECO mode [61] after the timer has elapsed
10	Timer_running_time			The runtime of the timer is given in seconds
11	Password_remote			Storage of a password with a maximum of 4 digits for remote access via the communication interface, input using the keyboard screen
12	Function_digital_input			Mapping of digital input function [98] to mainboard
		0	Off	Not used
		10	ECO	Brief application of an auxiliary voltage [105] by means of a pushbutton [106] switches ECO mode on
		30	Timer_start	Brief application of an auxiliary voltage [105] by means of a pushbutton [106] switches ECO mode on
		40	Power_limitation	Application of an auxiliary voltage [105] by means of a switch (NO) switches power limitation on for load shedding [101]
14	Control_curve			Behaviour during cold start or specification for special applications (only ELDB [77]), see [68]
		0	Energie-optimized	Current during cold start is 128% of rated current for fast heating
		1	Load-optimized	Current during cold start is 113% of the nominal current, to avoid overloading the supply network despite fast heating
		2	Process-optimized	Particularly fine control for critical applications
15	Delay_humidificat_notif.			Delay of "Humidifying" message in [s] (see [74])
16	Assignment_main_relay			The relay is energised if ...
		0	Collective_fault	There is any kind of error
		1	Safety_interlock_open	The interlock (safety) system [11] is open
		2	No_Demand	No request [5] is present
		3	Humidification	Steam production is in progress
		4	Runtime_limitation	The unit has switched off steam production after the limitation of operating time was reached [32]
		5	Remote_off	A remote shutdown was carried out via software command [12]
		6	Safety_interlock_ELV	The interlock (safety) system [11] is switched via an additional relay
		7	Safety_interlock_closed	The interlock (safety) system [11] is switched as standard
		8	Humidification_off_delay	A dropout delay [74] is to be generated following humidification
		30	Soleniod_valves_off	None of the solenoid valves are actuated
		31	Soleniod_valves_on	One of the solenoid valves is actuated
		32	Soleniod_valve 1	Solenoid valve 1 is actuated
		33	Soleniod_valve 2	Solenoid valve 2 is actuated
		36	HyFlush	The superflush SV is switched via the contacts of this relay

Function parameters (ctd.)

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold min max FP	Meaning/comment [] explains the term in the glossary → [] refers to a related term explanation
16	Assignment_main_relay			The relay is energised if ...
		0	Collective_fault	There is any kind of error
		1	Safety_interlock_open	The interlock (safety) system [11] is open
		2	No_Demand	No request [5] is present
		3	Humidification	Steam production is in progress
		4	Runtime_limitation	The unit has switched off steam production after the limitation of operating time was reached [32]
		5	Remote_off	A remote shutdown was carried out via software command [12]
		6	Safety_interlock_ELV	The interlock (safety) system [11] is switched via an additional relay
		7	Safety_interlock_closed	The interlock (safety) system [11] is switched as standard
		33	Solenoid_valve 2	Solenoid valve 2 is actuated
		36	HyFlush	The superflush SV is switched via the contacts of this relay
		210	Dehumidification	A downstream dehumidifier is to be actuated →[50]
		211	Humidity_reached	The value set in the "Control 21" parameter (Humidity_notification) has been reached
		270	Collective_service	A general service message is generated
		274	Service_main_contactor K1	A service is required after the max. operating cycles for K1 have been reached
		275	Service_main_contactor K2	A service is required after the max. operating cycles for K2 have been reached (only for double cylinder units)
		276	Service_main_contactor K3	A service is required after the max. operating cycles for K3 have been reached (only for double cylinder units)
		277	Service_main_contactor K4	A service is required after the max. operating cycles for K4 have been reached (only for double cylinder units)
		278	Service_main_contactor K5	A service is required after the max. operating cycles for K5 have been reached (only for double cylinder units)
17	Assignment_relay 1		see above	Relay 1 is one of the top-hat rail relays connected to the ST10.1 connector on the mainboard; assignment is same as for base relay
18	Assignment_relay 2		see above	Relay 2 is the second of the top-hat rail relays connected to the ST10.1 connector on the mainboard; assignment is same as for base relay
19	Assignment_relay 3		see above	Relay 3 is one of the top-hat rail relays connected to the ST10.2 connector on the mainboard; assignment is same as for base relay
20	Assignment_relay 4		see above	Relay 4 is the second of the top-hat rail relays connected to the ST10.2 connector on the mainboard; assignment is same as for base relay

5.8.9 Communication interface sub-menu



Table of communication interface parameters

The communication interface is a serial RS285 computer interface for the remote control of the steam humidifier. With this computer interface, all control operations which can be carried out on the screen can also be carried out by the building technology control system, for example.

The MODBUS-RTU Protocol is used to transmit the control commands (separate documentation on this is available from HygroMatik).

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold	Meaning/comment [] explains the term in the glossary →[] refers to a related term explanation
1	Address		0 255 1	Address of the communication interface [13]
2	Baud_rate			Setting the baud rate
		0	1200	1200
		1	2400	2400
		2	4800	4800
		3	9600	9600
		4	19200	19200
		5	28800	26800
		6	38400	38400
		7	57600	57600
3	Parity			Parity setting
		0	None	Without parity bit
		1	Odd	Odd parity bit
		2	Even	Even parity bit
4	Stop_bits			Number of stop bits
		0	1	1 stop bit
		1	2	2 stop bits
5	Modbus_timeout		0 60 20	Timeout in s for software control commands [12] through communication interface [13]

5.8.10 Timer submenu

The timer is used to program two switching time ranges per day of the week, each defined by "Start time" and "End time". A humidity target value can be assign to each switching time range.

Table of "Timer" parameters

No.	Parameter	No.	Adjustment/value range			Meaning/comment [] explains the term in the glossarF →[] refers to a related term explanation
			min	max	FP	
1	Mon_start_time 1		00:00	23:59	08:00	Start time 1 for Monday (1st period) →[91]
2	Mon_stop_time 1		00:00	23:59	12:00	End time 1 for Monday
5	Mon_humidity_set_value 1		5,0	99,9	50,0	Humidity set value [% RH] for the 1st period on Monday
6	Mon_start_time 2		00:00	23:59	13:00	Start time 2 for Monday (2nd period) →[91]
7	Mon_stop_time 2		00:00	23:59	20:00	End time 2 for Monday
10	Mon_humidity_set_value 2		5,0	99,9	50,0	Humidity set value for the 2nd period on Monday

The table only shows the possible parameter settings for Monday. The paramters for the rest of the weekdays (Tuesday to Sunday) can be programmed in the same way.

5.8.11 Recording submenu




The control can record 10 data sets internally on a rolling basis (Recording submenu, parameter 1 set to „On“). Snapshots of the unit status are carried out at intervals of 10 s, which can be helpful for troubleshooting. When all memory slots are filled, a new set of data overrides the oldest entry. A recorded set of data is conserved for a period of max. 7 days.

The complete record [93] can be saved to a USB stick with NTFS formatting.

For saving, pls. proceed as follows:

- » Call up recording submenu.
- » Set parameter „Saving_start“ (2) to „On“.
- » Insert USB stick in connector on mainboard (s. drawing below). Saving starts automatically. Then, parameter „Saving_start“ returns to the „Off“-state.

USB connector on mainboard



By looking at parameter „Saving_status“ (4) the status of the saving procedure can be checked. „Activated“ means that writing to the memory stick is underway.

Erasing of the complete memory is achieved by setting the „Recording_delete“ parameter (5) to „On“.

A data set consists of the following values:

No.	Value	only
1	Steam_actual_unit	
2	Steam_actual_Cyl. 1	DZG
3	Steam_actual_Cyl. 2	DZG
4	Status_unit	
5	Status_cyl. 1	
6	Status_cyl. 2	DZG
7	Fault message_unit	
8	Fault message_cyl. 1	
9	Fault message_cyl. 2	DZG
10	Safety interlock_open	
11	Demand	
12	Steam_output_max.	
13	Current_actual_Cyl. 1	ELDB
14	Current_actual_Cyl. 2	ELDB DZG
15	Water_level_cyl. 1	HKDB
16	Water_level_cyl. 2	HKDB DZG
17	Humidity_actual value	
18	Humidity_set value	2S
19	Humidity_actual_value_max	2S
20	Humidity_set_value_max	

Legend:

ELDB = Electrode Steam Humidifier

HKDB = Heater Element Steam Humidifier

DZG = Double Cylinder Unit


Table of recording functions

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold	Meaning/comment [] explains the term in the glossary → [] refers to a related term explanation
1	Recording	0	Deactivated	Recording [93] of parameter sets
		1	Activated	No recording
2	Saving_start			Start recording
		0	Off	Saving of the existing recording on a USB stick → [89]
		1	On	No action
3	Saving_abort			Start saving process
		0	Off	Cancel saving
		1	On	No action
4	Saving_status			Cancel saving process
		0	Deactivated	Status of saving process
		1	Activated	Saving not possible
5	Recording_delete			Saving is enabled
		0	Off	Delete recording
		1	On	No action
				Delete recording

5.8.12 Relay extension 1 submenu



The icon is only visible in the main menu if relay extension 1 has been activated in the functions submenu. The assignment of the respective relays and the function definition of the digital input present on the relay card can be made here.



Relay designations on relay extension 1 p.c.b.


Table of possible assignments

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold	Meaning/comment [] explains the term in the glossary → [] refers to a related term explanation
1	Assignment_relay 5		as base relay	Occupancy selection as for basic relay (see submenu "Functions", 15)
2	Assignment_relay 7		as base relay	Occupancy selection as for basic relay (see submenu "Functions", 15)
3	Signal_type_V_range		as base relay	Occupancy selection as for basic relay (see submenu "Functions", 15)
4	Signal_type_mA_range			Mapping of the digital input function [98] to relaF board 1
		0	Off	Not used
		10	ECO	Brief application of an auxiliary voltage [105] by means of a pushbutton [106] switches ECO mode on
		30	Timer_start	Brief application of an auxiliary voltage [105] by means of a pushbutton [106] switches ECO mode on
		40	Power_limitation	Application of an auxiliary voltage [105] by means of a switch (NO) switches power limitation on for load shedding [101]
5	Signal_type_mA_range			Selection of value range for input signal [72] with voltage curve
		0	Off	
		1	0...10 V	
		2	0...20 V	
		3	0...5 V	
		4	2...10 V	
6	Correction_V_signal		-5,0 5,0 0	Selection of value range for input signal [72] with voltage curve
7	Correction_mA_signal			Selection of value range for input signal [72] with current curve
		0	Off	
		1	0(4)...20 mA	
		2	0...12 mA	
		3	4...20 mA	
8	Correction_mA_signal		-5,0 5,0 0	Correction [49] of an input signal [72] with current curve
9	Signal_type_Ω_range			Selection of value range for input signal [72] with resistance curve
		0	Off	
		1	0...140 Ω	
		2	NTC15K	
10			-5,0 5,0 0	Correction [49] of an input signal [72] with resistance curve

5.8.13 Relay extension 2 submenu



The icon is only visible in the main menu if relay extension 2 has been activated in the functions submenu. The assignment of the respective relays and the function definition of the digital input present on the relay card can be made here.




Relay designations on relay extension 2 p.c.b.

Table of possible assignments

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold	Meaning/comment [] explains the term in the glossarF →[] refers to a related term explanation
1	Assignment_relay 8		as base relay	
2	Assignment_relay 9		as base relay	Occupancy selection as for basic relay (see submenu "Functions", 15)
3	Assignment_relay 10		as base relay	Occupancy selection as for basic relay (see submenu "Functions", 15)
4	Digital_input_function			Mapping of the digital input function [98] to relay board 2
		0	Off	Not used
		10	ECO	Brief application of an auxiliary voltage [105] by means of a pushbutton [106] switches ECO mode on
		30	Timer_start	Brief application of an auxiliary voltage [105] by means of a pushbutton [106] switches ECO mode on
		40	Power_limitation	Application of an auxiliary voltage [105] by means of a switch (NO) switches power limitation on for load shedding [101]
5	Signal_type_V_range			Selection of value range for input signal [72] with voltage curve
		0	Off	
		1	0...10 V	
		2	0...20 V	
		3	0...5 V	
		4	2...10 V	
6	Correction_V_signal		-5,0 5,0 0	Correction [49] of an input signal [72] with voltage curve
7	Signal_type_mA_range			Selection of value range for input signal [72] with current curve
		0	Off	
		1	0(4)...20 mA	
		2	0...12 mA	
		3	4...20 mA	
8	Correction_mA_signal		-5,0 5,0 0	Correction [49] of an input signal [72] with current curve
9	Signal_type_Ω_range			Selection of value range for input signal [72] with resistance curve
		0	Off	
		1	0...140 Ω	
		2	NTC15K	
10	Correction_Ω_signal		-5,0 5,0 0	Correction [49] of an input signal [72] with resistance curve

5.9 Screen 4 - Unit information

After an error or a status message has occurred, a display which provides information about the type of message appears in the main screen instead of the HygroMatik logo.



Touching this display field calls up the unit info page which extends over several screen pages and contains comprehensive device data. As an example, one possible first screen page is shown here:

< 02: Information	
01:Error message_unit	
Plug_ST09	
02: Error_message_cyl. 1	
Plug_ST09	
04: Service_message_cyl. 1	
No_service_message	
06: Unit type	FLE20-AA10
	>

The content of the screen pages is provided in the table in the next section.

Entries on the unit info screen

No.	Parameter	No.	Adjustment/value range Factory presets (FP) bold min max FP	Meaning/comment [] explains the term in the glossary → [] refers to a related term explanation
1	Fault_message_unit			Fault messages
		0	No_fault	No error
		1	Plug_ST09	The plug for the current transformer (ELDB [77]) or the level control (HKDB [78]) is not attached
		2	Cylinder_extension 1	There is a problem with the expansion board (double cylinder units only)
		6	Relay_extension 1	There is a problem with relay board 1
		7	Relay_extension 2	There is a problem with relay board 2
		24	Input_resistance_OC	Minimum value of resistance input not plausible
		25	Input_resistance_SC	Maximum value of resistance input not plausible
		29	Internal	System error
		30	Filling_valve 1	Error SV1 [19]
		32	Filling_valve 1 a. 2	Error SV2 [19]
		61	Part_blow-down	Error SV1, SV2, SV3, SV4
		62	Full_blow-down	Partial blow-down [21] not successful
		63	Blow-down_dilution	Full blow-down [22] not successful
		64	Max_current_blow-down	Dilution [23] was not successful (only for ELDB [77])
		65	Max_level_blow-down	Overcurrent blow-down [24] was not successful (only for ELDB [77])
		66	Standby_blow-down	Max. level blow-down [25] was not successful (only for HKDB [78])
		67	Start_blow-down	Stand-by blow-down [26] not successful
		90	Cylinder_full	Start blow-down [20] not successful
		91	Current_measurement	Sensor electrode reports cylinder full status [38] for 60 min (only for ELDB [77])
		92	Main_contactor_current	Value provided by current measurement not plausible (only for ELDB [77])
		93	Main_contactor_cyl_full	A current is measured for at least 15 s, even though the main contactor [72] is not actuated (only for ELDB [77])
		120	Thermoswitch	Temperature monitoring has been triggered on an electrode plug
		121	Water_level_sensor	A thermo sensor [31] has been triggered (only for HKDB [78])
		122	Max.-level	Value provided by level control [39] not plausible (only for HKDB [78])
		123	Steam_down_time	Max. level [40] was reached 5 times in a row during filling (HKDB [78] only)
		124	Relay_main_contactor	The relay for the control of the main contactor is not functioning correctly
		210	Humidity_sensor	Humidity sensor, cable or input level defective
2	Fault_message_cyl. 1			see above
3	Fault_message_cyl. 2			see above
5	Service_message_cyl. 1			Cylinder 1 service message
		0	No_service_msg.	A service is not required
		1	Steam_amount_counter	A unit service is required due to the steam volume counter
		2	Cycles_main_contactor 1	The maximum number of operating cycles for K1 has been reached and a Service_main_contactor [34] is required
		3	Cycles_main_contactor 2	The maximum number of operating cycles for K2 has been reached and a Service_main_contactor [34] is required (only double cylinder units)
		12	Warning_electrodes	The electrode wear is very advanced (only for ELDB [77])
		13	Warning_pump	A loss of functional performance has occurred in the area of the blow-down pump(s)
		14	Warning_solenoid_valve	A loss of functional performance has occurred in the area of the solenoid valve(s)
6	Service_message_cyl. 2			Cylinder 2 service message (double cylinder units only)
		0	No_service_msg.	A service is not required
		1	Steam_amount_counter	A unit service is required due to the steam volume counter
		4	Cycles_main_contactor 3	The maximum number of operating cycles for K3 has been reached and a Service_main_contactor [34] is required
		5	Cycles_main_contactor 4	The maximum number of operating cycles for K4 has been reached and a Service_main_contactor [34] is required
		6	Cycles_main_contactor 5	The maximum number of operating cycles for K5 has been reached and a Service_main_contactor [34] is required
		12	Warning_electrodes	The electrode wear is very advanced (only for ELDB [77])
		13	Warning_pump	A loss of functional performance has occurred in the area of the blow-down pump(s)
		14	Warning_solenoid_valve	A loss of functional performance has occurred in the area of the solenoid valve(s)

Entries on the unit info page (ctd.)

7	Model		Reading value	Type designation of unit
8	Unit_name		Unit 1	Freely selectable text ex-factory. "System 1" is entered if this is not specified in the order. Entry can be overwritten in the field using the service tool.
9	Serial_number		Reading value	Serial number
10	Date_of_manufacturing		Reading value	Total operating time of unit since initial operation (specified in s)
11	Software_version		Reading value	Software version
12	Production_total_time		Reading value	Total duration of steam production since initial operation (specified in s)
13	Unit_total_runtime		Reading value	The total runtime of the unit since its first connection to the power supply
14	Steam_amount_total_cyl. 1		Reading value	Steam volume of cylinder 1 produced since initial operation
16	Steam_amount_total_cyl. 1		Reading value	Steam volume of cylinder 2 produced since initial operation (only for double cylinder units)

6. Faults and Warnings

6.1 Fault Management

In the event of a fault, the steam production is halted. The relevant display field is then shown instead of the HygroMatik logo. The display field shows a warning symbol, the „Fault“ message and - in paranthesis - the fault code:




e.g.:





When touching the fault message display field, the unit info screen opens with the fault message in plain text and information concerning the unit and its current state.





The majority of fault messages is additionally accompanied by the flashing of one or more icons, allowing for a first limitation of the cause of fault.






6.1.1 Table of Fault Messages, possible Causes and Countermeasures



These icons flash	Fault Code	Fault message	Possible cause	Countermeasure
 	001	Plug_(ST09) The plug for the current transducer or the water sensor is not connected.	<ul style="list-style-type: none"> • Plug sits not firmly or is not in place 	<ul style="list-style-type: none"> • Check plug and connect, if required
	002	Cylinder_extension Extension board not detected by the software.	<ul style="list-style-type: none"> • P.c.b. connection not o.k. • P.c.b. not present or defective • CAN-Bus addressing not correct 	<ul style="list-style-type: none"> • Check firm connection of boards • Connect board, replace board if defective • Check DIP switch settings on extension board (both switches must be in the „zero“ position)
	006 007	Relay_extension 1 Relay_extension 2 Relay board (s) not detected by the software.	<ul style="list-style-type: none"> • P.c.b. connection(s) not o.k. • P.c.b.(s) not present or defective • CAN-Bus addressing not correct 	<ul style="list-style-type: none"> • Check firm connection of boards • Connect board(s), replace board(s) if defective • Check DIP switch settings on relay boards (both switches must be in the „zero“ position)
	024 025 (*)	Input_resistance_OC Input_resistance_SC The resistance measured is not correct („infinite“ or „zero“, resp.)	<ul style="list-style-type: none"> • Sensor, wiring or signal source defective • Input stage defective 	<ul style="list-style-type: none"> • Check sensor, wiring and signal source, if relevant • Replace main board





*) When the PI controller is in use, faults 024 and 025 relate to the sensor. In case of an external controller, the signal source is referred to.

These icons flash	Fault Code	Fault message	Possible cause	Countermeasure
	029	Internal	<ul style="list-style-type: none"> • Main board is defective 	<ul style="list-style-type: none"> • Replace mainboard
	030 032	Filling_valve 1 Filling_valve 1 a. 2 Filling was not successful, i.e. the expected filling level was not achieved after 30 mins of filling.	<ul style="list-style-type: none"> • Solenoid valve or water supply line contaminated or defective • Solenoid valve defective • Water supply not opened • Solenoid valve electrically not driven <ul style="list-style-type: none"> - electrical cabling not o.k. - Mainboard relay not energised • Steam hose not laid with sufficient incline/decline resulting in a water bag obstructing steam flow. Steam builds up pressure in steam cylinder and pushes water towards drain • Blockage in steam pipe impedes the steam flow. The steam builds up pressure in the cylinder and presses the water into the drain. • L3 phase break-down • Main contactor does not switch L3 phase 	<ul style="list-style-type: none"> • Clean water supply line and/or solenoid valve; replace solenoid valve, if defective • Make measurement on solenoid; replace solenoid valve, if defective • Open water supply - Check electrical cable and replace, if required - Measure voltage on mainboard terminal 11 against N; replace mainboard, if required • Check steam hose layout. Eliminate water bag. • Remove blockage in steam pipe • Reestablish L3 phase feeding • Replace main contactor

These icons flash	Fault Code	Fault message	Possible cause	Countermeasure
	061 062 063 064 065 066 067	Part._blow-down Full_blow-down Blow-down_dilution(only ELDB) Max._current_blow-down (only ELDB) (Max._level_blow-down (only HKDB)) Standby_blow-down Start_blow-down (only HKDB) The respective blow-down was not successful.	<ul style="list-style-type: none"> • Blow-down pump is not driven - electrical wiring is not o.k. - Mainboard relay is not energised <ul style="list-style-type: none"> • Blow-down pump defective • Blow-down pump is working but water is not drained (i.e. cylinder drain is blocked) • Blow-down pump blocked by scale deposits • Water sensor defective (only HKDB) 	<ul style="list-style-type: none"> - Check wiring and replace, if required - Measure voltage on mainboard terminal 10 against N; replace mainboard, if required <ul style="list-style-type: none"> • Replace blow-down pump • Check blow-down pump, drainage system and steam cylinder for hardeners and clean • Check blow-down pump, drain system and cylinder for scale deposits and clean • Replace water sensor
	090	Cylinder_full (only ELDB) The sensor electrode consistently reports cylinder full status for 60 min	<ul style="list-style-type: none"> • Low or widely fluctuating water conductivity • Electrodes worn out • No electrode cable run through current transducer • Salt bridges in steam-cylinder upper part • Foaming (when softened water is used) 	<ul style="list-style-type: none"> • Check feed water quality; consult your expert dealer, if required • Replace electrodes • Run one phase through current transducer • Clean • Increase blending rate (bigger raw water proportion)
 	091	Current_measurement (only ELDB) The current transducer reading is not correct	<ul style="list-style-type: none"> • Plug is not seated properly on mainboard • Current transducer defective 	<ul style="list-style-type: none"> • Check plug seating • Replace current transducer






These icons flash	Fault Code	Fault message	Possible cause	Countermeasure
	092	Main_contactor_current (only ELDB) A current is measured though the main contactor is not driven.	<ul style="list-style-type: none"> • Main contactor contact sticks 	<ul style="list-style-type: none"> • Replace main contactor
	093	Main_contactor_cyl._full (only ELDB) „Cylinder full“ is detected though the main contactor is not driven.	<ul style="list-style-type: none"> • Main contactor contact sticks 	<ul style="list-style-type: none"> • Replace main contactor
	120	Thermoswitch (only HKDB) Minimum one of the thermoswitches has tripped.	<ul style="list-style-type: none"> • Thermoswitch on steam cylinder cover has tripped due to lime coating on heating element • Capillary tube defective • Thermo switch on solid state relay has triggered due to blocked ventilation 	<ul style="list-style-type: none"> • Switch off power supply. Remove lime coating. Allow cool-down of steam cylinder. Push-back unblocking pin on thermoswitch with needle-nose pliers or a screwdriver • Replace thermoswitch • Switch off unit. Allow cool-down of heat sink. Remove blockage. Ensure unobstructed ventilation. Restart humidifier operation.
 	121	Water_level_sensor (only HKDB) The water sensor reading is not plausible.	<ul style="list-style-type: none"> • Water sensor is defective • Connecting hoses blocked 	<ul style="list-style-type: none"> • Replace water sensor • Clean hoses

These icons flash	Fault Code	Fault message	Possible cause	Countermeasure
 	122	Max.-level (only HKDB) Water level has reached its maximum 5x in one single steam production phase.	<ul style="list-style-type: none"> • Excessive air pressure in duct has impact on water in steam cylinder via steam hose. Water is pressed into drainage • Solenoid valve closing action imperfect. Cylinder water level rises though solenoid valve is not energised • Solenoid valve is permanently energised (water intake stops when unit is switched off) • Large amounts of residues influence or restrict cyclic blow-down. The additional water introduction caused by the optional HyFlush rinse device may cause the max. level fault 	<ul style="list-style-type: none"> • Reduce air pressure, check steam hose for blockages • Check solenoid valve • Relay contacts on mainboard stick. Measure voltage across terminal 11 and N; replace mainboard, if required • Clean steam cylinder, cylinder base, water sensor tubing and drainage system

These icons flash	Fault Code	Fault message	Possible cause	Countermeasure
 	123	Steam_down_time (only HKDB) The heaters are supplied with current, but water level doesnot change.	<ul style="list-style-type: none"> • Heater element is defective • Phase failure (external circuit breaker has tripped or is defective) • Heater elements not supplied with voltage • Main contactor switching not o.k. • Main contactor not driven by mainboard relay 	<ul style="list-style-type: none"> • Measure heater element resistance; replace heater element, if required. Nominal resistance values are: FLH03 - 2.25 kW / 230 V - 21.3 - 26.1 Ω FLH06 – 4.5 kW / 400 V – 32.3 - 39.5 Ω FLH09 – 6.75 kW / 400 V - 21.5 - 26.3 Ω FLH15 – 3.8 kW / 400 V – 38.2 - 46.8 Ω (3x) FLH25 – 6.3 kW / 400 V – 23.1 - 28.2 Ω (3x) FLH30 – 3.8k W / 400 V - 38.2-46.8 Ω (6x) FLH40 – 6.3 kW / 400 V – 23.1 - 28.2 Ω (3x) + 3.8 kW / 400 V – 38.2 - 46.8 Ω (3x) FLH50 – 6.3 kW / 400 V – 23.1 - 28.2 Ω (6x) • Replace external circuit breaker, eliminate cause for tripping • Check wiring and voltage supply • Check main contactor; replace, if required • Measure voltage on mainboard terminal 9 against N; replace mainboard, if required
	124	Relay_main_contactor (only HKDB) The main contactor is not driven by the electronics on the mainboard, but a voltage is measured	<ul style="list-style-type: none"> • Mainboard relay contacts stick 	<ul style="list-style-type: none"> • Replace mainboard
	210 211	Humidity_sensor Humidity_sensor 2 The respective humidity sensor reading is implausible.	<ul style="list-style-type: none"> • Sensor cable defective • Sensor defective 	<ul style="list-style-type: none"> • Check sensor cable • Replace sensor

6.2 Servicemessages and warnings

Service messages and warnings are shown on the main screen in place of the HygroMatik logo, when the cause has occurred. When tipping the display field, the unit info screen is shown with the messages in plain text.

Mainscreen presentation	Message	Possible cause	Countermeasure
 Service	Steam_amount counter	The maintenance interval has expired.	Service or check steam humidifier. Reset the steam amount counter (also see chapter 5.8.4.1 Monitoring and service messages“).
 Service	Cycles_main_contactor X	The maximum number of operating cycles for the main contactor X has been reached and the main contactor should be changed. (The device can contain several main contactors. X represents the designation number of the main contactor concerned.)	The main contactor should be changed. After replacement, the respective counter must be reset with the parameter „Main_contactor_Kx_Reset“ (x=number of main contactor, 1...5). (Also see chapter 5.8.4.1 Monitoring and service messages“).
 Service	Warning_cyl._full (only ELDB)	Electrode wear is very advanced.	Replace Electrodes.
 Service	Warning_pump	A performance capability decrease is detected in the area of the blow-down pump and its hosing.	Check area and clean. If warning persists, replace blow-down pump.
 Service	Warning_valve	A performance capability decrease is detected in the area of the solenoid valve, cylinder base and its hosing.	Check area and clean. If warning persists check cylinder base for lime deposit.

The sensitivity threshold of the last three warning messages is set to the highest level ex factory. Should the on-site conditions (e.g. the water conductivity) lead to an unwanted frequent occurrence of the messages, the sensitivity can be reduced in the „Service“ submenu (s. section 5.8.4).

6.3 Table of functional disruptions

Problem	Possible cause for faulty situation	Countermeasure
Set humidity level not reached	<ul style="list-style-type: none"> • Output limitation parameter setting impedes full power output • Nominal unit output insufficient • Phase failure • Lengthy steam hose layout crossing cold and drafty rooms may lead to increased condensate formation • Improper steam manifold installation may cause condensate formation within air duct • Control signal not properly selected or software setting mismatch • Water quality requires water concentration for full steam output • Excessive pressure in duct system caused by e.g. water bags or partly blocked steam pipes (max. overpressure is 1200 Pa) 	<ul style="list-style-type: none"> • Check „Steam_output_max.“ parameter setting („Control“ submenu, line 2) • Check unit technical data, air-flow and secondary airflow • Check circuit breakers • Change unit installation location allowing for shorter steam hose. Insulate steam hose • Check steam manifold position within total system and installation correctness • Check control signal and „Control_settings“ parameter („Control“ submenu, line 1) • Wait • Eliminate particular cause(s)
Excessive humidity	<ul style="list-style-type: none"> • If steam output is too high, poor control performance may result and even condensate formation in ducts • Control signal not properly selected or software setting mismatch 	<ul style="list-style-type: none"> • Check „Steam_output_max.“ parameter setting („Control“ submenu, line 2) • Check control signal and „Control_settings“ parameter („Control“ submenu, line 1)


Problem	Possible cause for faulty situation	Countermeasure
Water collects on bottom plate	<ul style="list-style-type: none"> • Cylinder improperly reassembled following maintenance: <ul style="list-style-type: none"> - O-ring not replaced, defective or not in place - Flange (tongue and groove) damaged - Flange improperly composed - Mineral deposits in flange area • Cylinder improperly inserted in cylinder base • Water cannot drain freely when pumped from cylinder 	<ul style="list-style-type: none"> • Clean cylinder and assemble / install properly • Using moistened new O-ring, insert steam cylinder properly into cylinder base • Make sure drain is unobstructed
Water leaks from steam cylinder upper part	<ul style="list-style-type: none"> • Hose clamps on steam and/or condensate hose not tightened <p>Steam hose adapter not properly fit or O-ring not replaced</p>	<ul style="list-style-type: none"> • Tighten clamps <p>Replace O-ring (if required) and ensure proper adapter installation</p>
No steam production despite the steam humidifier being switched on. Display not illuminated	<ul style="list-style-type: none"> • Defective F1 and/or F2 fuses on main-board • External control voltage failure (ext. circuit breaker has tripped or is defective) • device load circuit breaker has tripped (only ELDB) 	<ul style="list-style-type: none"> • Check micro fuses and replace, if required • Replace breaker and investigate possible causes • Switch on breaker. If problem persists, check for reason
No steam production despite the steam generator being switched on and an illuminated display	<ul style="list-style-type: none"> • The interlock (safety) system is open • The humidity set value has been reached. The control receives no demand for steam production. • A fault has occurred 	<ul style="list-style-type: none"> • Close interlock (safety) system • Check humidity set value and plausibility of actual humidity value • Check unit status
No steam production. Voltage across electrodes exist, but no water is fed into the cylinder (only ELDB)	<ul style="list-style-type: none"> • Water supply not opened or solenoid valve electrically not driven 	<ul style="list-style-type: none"> • Open water supply (s. also Filling fault messages 030 and 032)


Problem	Possible cause for faulty situation	Countermeasure
Blow-down pump works but not water is drained	<ul style="list-style-type: none"> • Steam cylinder and/or drainage system blocked 	<ul style="list-style-type: none"> • Clean cylinder base and/or drainage system, respectively
Cylinder is fully drained after partial blow-down despite pump being switched off	<ul style="list-style-type: none"> • Vent pipe is blocked 	<ul style="list-style-type: none"> • Clean venting bore; replace vent pipe, if required
No steam exit from steam manifold	<ul style="list-style-type: none"> • Steam pipe improperly laid (water bag) or blockage 	<ul style="list-style-type: none"> • Rerun steam hose according to guide lines, remove blockage
Water exits periodically from drain hose without pump switched on	<ul style="list-style-type: none"> • Excess pressure in duct system (max. overpressure is 1200 Pa) 	<ul style="list-style-type: none"> • Lengthen drain hose system; consult your expert dealer if problem persists
Uneven electrode wear	<ul style="list-style-type: none"> • One or more electrodes not supplied with power • Circuit breaker tripped • Main contactor contact not functional • Phase loading not symmetric • Electrode immersion depth differs. Unit not mounted plumb 	<ul style="list-style-type: none"> • Check power supply and wiring • Check circuit breaker. Replace, if required • Check main contactor. Replace, if required • Ensure power supply phase balance by measurement • Check installation and correct positioning, if required

Problem	Possible cause for faulty situation	Countermeasure
Flashover/sparks in cylinder(only ELDB)	<ul style="list-style-type: none"> • Very high water conductivity resulting in massive electrode burn-off as indicated by brown-black deposits • Blow-down pump not working properly or defective 	<ul style="list-style-type: none"> • Deactivate unit immediately to prevent material damage <p>Perform maintenance:</p> <ul style="list-style-type: none"> - replace electrodes with high conductivity type - clean steam cylinder - check water quality and conductivity (also s. „Intended use“ section) - optimise blow-down parameters <p>Consult your expert dealer, if required</p> <ul style="list-style-type: none"> • Check blow-down pump functioning and replace pump, if required. See also fault messages 061 to 067 related to blow-down

7. Wiring Diagramms

7.1 FLE Single cylinder units






HYGROMATIK
Lise-Melner-Str. 3
24558 Hensled-Ulzburg
Tel.: +49/(0)4193/895-0
Fax: +49/(0)4193/895-33

(Zeichnung Nr.)
S-43-000A.02

FLE 05-65
heating voltage: 200 - 480V


07.12.2017
11.01.2018







<div> <div>HYGROMATIK</div> <div> Lise-Meiner-Str. 3 24558 Hensfeld-Ulzburg Tel.: +49/(0)4193/895-0 Fax: +49/(0)4193/895-33 </div> </div>		(Zeichnung Nr.)	
		S-43-001A.02	
FLE 05-65		heating voltage: 200 - 240V / 3	
Rev.	Änderung	Datum	Norm












A		release	11.11.17	Lue	Datum	07.11.2017	FLE 80-130		heating voltage: 380 - 480V		S-43-002A.04		HYGROMATIK Lise-Welken-Str. 3 24571 Hohenlockstedt Tel.: +49 (0)41 93 895-0 Fax: +49 (0)41 93 895-33	
		Rev.	Änderung	Datum	Name	Gepr.								





7.3 FLH Single cylinder units













7.4 FLH Double cylinder units





HYGROMATIK
Lise-Melner-Str. 3
24568 Hensel-Utzburg
Tel.: +49(0)4193/895-0
Fax: +49(0)4193/895-33

S-43-012A.02

FLH 80-100
heating voltage: 200 - 480V / 3

Rev.	Änderung	Datum	Name	Norm	Gepr.	Beerb.	Datum	07.11.2017	10.12.2018

FLH 80-100
heating voltage: 200 - 480V / 3

8. Glossary

Term	[Index]	Explanation
Actual value	1	The actual value is the measured value of a physical quantity, which is compared with the → <i>Set value</i> [3] during the control process and may give rise to a readjustment, if required.
Relative humidity (r.h.)	2	The relative humidity (r.h.) describes the maximum percentage of moisture which the ambient air can hold at a certain temperature.
Set value	3	The set value of a physical quantity (e.g. the → <i>r. h.</i> [2]) is the set target for a control process.
Steam output	4	The steam output calculated from the electrical power consumption in kg/h.
Demand	5	The demand describes the dimensionless control signal processed by the control system which is converted into a proportional → <i>Internal actuator signal</i> [42] for the power control for steam generation.
Hygrostat	6	Sensor with switching function for the → <i>Relative humidity (r.h.)</i> [2] in rooms. The trigger point for the switching function with potential free contacts can be set mechanically. The hygrostat can be used to control → <i>1 step operation</i> [44] or in the → <i>Interlock (safety) system</i> [11] to protect against excess humidity.
Update function	7	The update function provides the control with an update of parameter settings which is stored on an external USB memory stick. The "Update function" parameter is a read-only value which can be used to read out the status of the update.
SI system of units	8	The system of units with the temperature specified in °C and the quantity specified in kg.
Initialisation	10	The control performs a self-test, during which the welcome screen with the software version is displayed. After the parameter settings and measured values have been read in, the → <i>Main screen</i> [14] is shown on the display. During the subsequent start blow-down, the read values can be used to query the device status, which is "Initialisation" in this phase.
Interlock (safety) system	11	The hardware interlock (safety) system makes it possible to immediately interrupt steam production, e.g. using an emergency stop button or. The interlock (safety) system must be closed to operate the unit. The interlock (safety) system must be implemented on-site with one or several potential free contacts (switched in series). It is connected to the control at terminals 1 and 2, with terminal 1 carrying 230 VAC as standard. In a special design (e.g. for the U.S. market), the interlock (safety) system is converted to low voltage through the additional use of a relay to meet local safety requirements. Instead of terminals 1 and 2 on the control, a potential free connection of the relevant DIN rail terminals must then be implemented on-site. If the interlock (safety) system is opened, the status of the unit changes to "Interlock (safety) system open".
Software control command	12	Coded command, which is, for example, sent from the building control system or a PLC via the → <i>Communication interface</i> [13] to the control. The command set available is listed in separate documentation, which is available from HygroMatik on request.
Communication interface	13	Serial computer interface for remote control of the unit using, for example, the → <i>Modbus</i> [17] RTU protocol.
Main screen	14	Screen content during the normal operation of the unit. The main screen includes the main display (in the middle of the screen) and the status icons (left and right of the main display).
Standby heating	16	So that steam production can be started more quickly, the standby heating keeps the water in the cylinder warm, if no → <i>Demand</i> [5] is present. The → <i>Interlock (safety) system</i> [11] must be closed. Heating and pause times are adjustable.
Modbus	17	Modbus is a communications protocol for serial data transmission for the remote control of units, which is widely used in industry. HygroMatik controls use the MODBUS - RTU (remote terminal unit) variant. Separate documentation is available upon request from HygroMatik.
Timer function	18	The timer makes it possible to limit the duration of steam production in the short-time range, starting when steam production is halted (if no demand exists in normal operation), or ECO mode. The timer is triggered by pressing a button, which must be connected to the <i>digital input</i> [97] of the mainboard. In addition, the → <i>Digital function</i> [98] parameter must be set to "Timer_start". The "0" setting deactivates the timer. "1" or "2" is used to specify whether the steam is turned off or if there is a return to ECO mode after the timer has elapsed.
Solenoid valve (SV)	19	The solenoid valves for the water supply to the steam cylinder(s) are labelled with Y1, Y2, Y3 and Y4 in the circuit diagrams.
Start blow-down	20	The unit performs a → <i>Blow-down</i> [58] after it was switched off and has been switched on again. The process varies depending on the unit type. For the → <i>ELDB</i> [77] it is important that, when the main contactor is first switched, overcurrent due to excessive conductivity of the cylinder water does not occur while simultaneously water level is high. A → <i>Partial blow-down</i> [21] is therefore used to ensure that the current does not reach an impermissible value. This procedure is not required for the → <i>HKDB</i> [78]. The only checks carried out here are on the functioning of the level control and the blow-down pump, by carrying out a plausibility check of the measured value of the water level sensor which is transferred in the context of a → <i>partial blow-down</i> [21].
Partial blow-down	21	Only part of the cylinder water is pumped off during the → <i>Blow-down</i> [58]. For the → <i>ELDB</i> [77], a partial blow-down is carried out periodically after 40 solenoid valve operating cycles (fillings). For the → <i>HKDB</i> [78], the frequency of the partial blow-down is determined by the steam volume.
Full blow-down	22	All of the cylinder water is pumped off during the → <i>Blow-down</i> [58].
Dilution	23	A dilution is a → <i>Partial blow-down</i> [21], which is caused by excessive conductivity of the cylinder water. For deconcentration, fresh water is used to top up the cylinder after the partial blow-down.

Glossary ctd. (1)

Term	Index	Explanation
Max. level blow-down	25	When the water level sensor signals the maximum level, a → <i>Partial blow-down</i> [21] is carried out to reduce the water level (only for → <i>HKDB</i> [78]).
Stand-by blow-down	26	If the unit was switched on for an extended period without a → <i>Demand</i> [5] arising, or if the → <i>Interlock (safety) system</i> [11] was opened for an extended period, a (→ <i>Blow-down</i> [58]) of the cylinder water is performed to prevent germ formation. The interval for triggering the blow-down is defined with the "Standby_blow-down_interval" parameter.
Flushing of dead-end line	27	When this function is activated, the feed water line is flushed during operation phases in which there are no requests in order to prevent germ formation. For this purpose, the inlet solenoid valve and the blow-down pump are activated at the same time. The "Flushing_of_dead-end_line_interval" parameter determines when flushing starts after a request was not received, the "Flushing_of_dead-end_line_duration" parameter determines how long flushing takes. The interlock (safety) system must be closed so that the inlet solenoid valve can be controlled ("partially automatic flushing of dead-end line").
Manual blow-down	28	Pumping out of the cylinder water by touching the "Blow-down" icon on the screen or by a → <i>Software control command</i> [12] via the → <i>Communication interface</i> [13]. Repeated actuation or a corresponding → <i>Software command</i> [12] switches the → <i>Blow-down function</i> [58] off again). The cylinder water may also be pumped by setting the control switch on the device front panel in the "I" position while the control remains switched off.
Switch-off point	29	The switch-off point for switching off steam production with decreasing → <i>Demand</i> [5] is specified as a percentage value of the maximum control signal. The switch-off point is generally selected as > "0" to hide any errors on the control signal close to the zero value and thereby allow reliable switch-offs.
? Switch-on point	30	The difference value for the switch-on point specifies the percentage share of the max. control signal by which the switch-on point is to be above the switch-off point. It therefore determines the switching differential between switching off and switching on again and is also used to prevent the unit from being frequently switched on and off unnecessarily. Example: Switch-off point 20%, ? Signal_switch-on_point 5% , signal type voltage control in the range 0... 10 V, the switch-on point is then at 2.5 V, the switch-off point at 2.0 V.
Thermo sensor	31	With the → <i>HKDB</i> [78], a thermo sensor is located on the cylinder cover, connected to the heater - or if available - both heaters via a capillary tube. A thermal switch is also arranged on every → <i>Solid state relay</i> [46] . All thermo sensors/thermal switches are connected in series. If one of the thermo sensors/thermal switches is triggered, the power supply to the steam humidifier is interrupted. The thermo sensor(s) on the cylinder(s) have to be reset mechanically after cooling down. The thermal switches are automatically reset after cooling down.
Limitation of operating time	32	The unit stops the steam production according to the number of minutes specified. The time is counted from the point when the interlock (safety) system was closed. To put the unit back into operation, the interlock (safety) system must be opened and closed again, or the → <i>Communication interface</i> [13] must be used to transmit → <i>Software control commands</i> [12] to open and close the virtual interlock (safety) system again. Alternatively, the control switch can also be opened and closed again. This does, however, cause the unit to be restarted. Setting the parameter to a value of "0" deactivates the limitation of operating time.
Service_steam_volume	33	The steam volume produced [kg] is compared to the default value set in the "Steam_volume_service" parameter to obtain a criterion for maintenance requirements. Once the default value has been reached, the message "Service_steam_volume" is displayed. Once the service has been performed, the steam volume counter has to be reset with "Service_interval_reset". The remaining steam volume can be viewed using the "Steam volume until message" read value.
Service_main_contactor	34	The operating cycles of the main contactor(s) are recorded by counters and compared to factory-set default values by the software. When a default value is reached, the "Service_main_contactor" message is displayed on the screen. After a main contactor has been replaced, the respective counter must be reset with the parameter "Main_contactor_Kx_Reset" (x = number of the main contactor, 1...5).

Glossary ctd. (2)

Term	Index	Explanation
Floating max. limiter	35	<p>The floating max. limiter serves for protection against excessive humidification of the channel. In case of the room sensor sending a demand while the channel has already reached its maximum humidity capacity, a floating max. limiter allows for a much more sensitive limitation of the steam supply when compared to a max. hygrostat. While the max- hygrostat switches off only when the maximum humidity is reached, the floating max. limiter tracks the humidity progress and turns down the steam production based on a settable control curve until a defined max. humidity is reached. This aims to ensure that no excessive humidification may occur in the channel.</p> <p>To use this function, a 2nd humidity sensor must be mounted in the channel (typical mouting position is the range where the steam is introduced into the channel by the humidifier).</p> <p>Connecting the 2nd humidity sensor</p> <p>If the unit only features a mainboard (i.e. no additional relay board), the 1st humidity sensor must be of the "Humidity sensor with 0...10 V output voltage" type to allow for the implementation of the floating max. limiter function. The secon humidity sensor is than wired to the current input of the mainboard. To allow for this, the sensor must feature a 4...20 mA current output signal. In case of a relay board built into the unit, however, the 2nd humidity sensor is to be wired to this board making use of the 0...10 V voltage input, just as is the case with the mainboard. Consequently, the humidity sensor must be of the 0...10 V voltage type.</p> <p>Activating the floating max. limiter</p> <p>Activating is accomplished by setting the "Control settings" parameter in submenue "Control" to "11" or "12". The setting must be in accordance with the wiring chosen for the 2nd humidity sensor. If no 2nd humidity sensor is connected, the parameter setting is not saved.</p> <p>Example: The 2nd humidity sensor was connected to the current input of the mainboard. For the "Control settings" parameter, the "11" is to be chosen as the setting value.</p> <p>Parameter settings for the floating max. limiter</p> <p>For the floating turning-down of the humidity set value, the control curve steepness may be set with the "PI-controller_max_gain" parameter. Factory pre-setting (FP) is "5". The humidity set value for the shut-down point is defined by the "Humidity_set_max" parameter (FP = 80%).</p>
Cylinder full status	38	When the unit measures a potential at the sensor electrode, it reports a cylinder full status. In this case, the cylinder water level is so high that it creates an electrical bridge between one of the power electrodes and the sensor electrode. If the cylinder full status continues for an hour, steam production is shut down and a fault message is generated.
Level control	39	With the → <i>HKDB</i> [78], communicating tubes are used for the contact-free measurement of the water level in the cylinder.
Max. level	40	The maximum water level value supplied by the → <i>Level control</i> is reached. If this state is reached 5x in succession within a predefined time interval, the control issues a "Error_max.level" message (only → <i>HKDB</i> [78]).
Internal actuator signal	42	Actuator signal for the control of the power element of the unit concerned.
Max. steam output	43	Reduction of output power to 25... 100% of the nominal output. Can lead to improved control behaviour at lower output requirements.
1 step operation	44	On/off operation of the steam humidifier without control function through a potential free contact suitable for low voltage, to be supplied on-site. The control can, for example, be implemented using a → <i>Hygrostat</i> [6], which has to be connected to a potential free make contact between terminals 3 and 5 of the control.
Solid state relay (SSR)	46	
Humidification	47	The unit produces steam, if a → <i>Hygrostat</i> [6], an → <i>External control</i> [73], a Humidity sensor or a → <i>Software control command</i> [12] has issued a → <i>Demand</i> [5] and the → <i>Interlock (safety) system</i> [11] is closed.
PWM	48	Pulse width modulation with variable frequency and variable duty cycle for the control of the heater current via the → <i>Solid state relay</i> [46]. Because the heater current determines the steam output, it is possible to control the steam output in this way (only for → <i>HKDB</i> [78]).
Correction_x_signal	49	Used for the calibration of a humidity sensor output signal as the → <i>Input signal</i> [72] of the control (x = "V", "mA", "Ω").
Δ Dehumidifying	50	Specifies the percentage by which the → <i>Set value</i> [3] of the → <i>r.h.</i> [2] has to be exceeded until the "Dehumidify" signal becomes available at the selected relay, if this relay is set to "210".
Δ Humidity_ECO	51	To conserve energy, the → <i>set value</i> [3] of the → <i>r.h.</i> [2] can be lowered by the value stored in "Humidity_ECO". For this purpose, a → <i>pushbutton</i> [106] has to be wired to the → <i>Digital input</i> and the function of the digital input has to be programmed to "ECO". This function is available only in connection with the "PI controller" control type.
Evaporation_time_to_error	53	If the level of the cylinder water has not changed within the time defined in this parameter, this indicates that a malfunction is present. The steam production is then suspended and the "Evaporation time" error message is output (only → <i>HKDB</i> [78]).
Filling_cycled	54	The fill operation does not take place continuously, but with breaks, in order to prevent the overflowing of the filling cup (HyFlow). Filling and pause intervals can be adjusted separately.
Blow-down correction	55	If the water has high electrical conductivity or if there is a very high level of maintenance, it may be useful to increase the blow-down frequency. At low electrical conductivity, however, a reduction in the frequency of the blow-down may be useful. Depending on the water quality, the blow-down rate can be adjusted in 10 steps ("0" is the default). More frequent blow-down: Values up to max. +5, less frequent blow-down values down to -5, whereby "-5" means that blow-down is completely switched off.

Glossary ctd. (3)

Term	[Index]	Explanation
Pumps_without_main_contactor	56	In rare cases, leakage currents may flow through the water to the earth during the blow-down process. To prevent a sensitive FI switch from being triggered, the main contactor can be switched off during the pumping process (only → <i>ELDB</i> [77]).
HyFlush (option)	57	When open, an additional solenoid valve produces a rotating turbulence for an improved discharge of scale deposits during blow-down. The solenoid valve is controlled by the software with a fixed ratio of active and pause times.
Blow-down	58	Pumping off the water in the cylinder for the following reasons: Elimination of scale deposits, replacement of water to prevent germ formation and reduction of conductivity (only → <i>ELDB</i> [77]), which increases due to evaporation and leads to increased power consumption. A distinction is made between → <i>Full blow-down</i> [22] and → <i>Partial blow-down</i> [21].
HyCool (option)	59	Waste water cooling system for the protection of temperature-sensitive plastic waste water pipes. A solenoid valve is used to mix fresh water with the waste water so that the water temperature does not exceed 60 °C.
ECO mode	61	Lowering of → <i>Humidity set value</i> [3] to conserve energy.
Power level	63	If the → <i>HKDB</i> [78] is equipped with 3 heaters, the power is provided in 2 levels from a certain performance class onwards. As long as a certain threshold value has not been reached, the heating performance required in level 1 is exclusively provided proportionally via the → <i>Solid state relay</i> [46]. After reaching the threshold value, the heater(s) is/are energised for "base performance" in level 1 via the contactor in 1 step operation. The power requirement which exceeds the "base performance" is then covered proportionally by the solid state relay in level 2.
Relay assignment	65	If the basic relay or additional relays which may be present are not used for signalling but for direct load switching, the maximum contact load 250 VAC/8 A must be taken into account
Control curves	68	In the "Load optimised" factory setting, the power control of an → <i>ELDB</i> [77] is set so that a current of 113% of the nominal current is permitted during a cold start to avoid overloading the power supply. In the "Energy optimised" setting, the current is increased to 128% of the nominal current during a cold start for achievement of a preferably short heat-up period. In the "Process optimised" setting, control is particularly fine.
Output signal	69	Signal 0... 10 V on terminals 12 and 13 (GND), which is proportional to the input signal. Can be used to control downstream units.
Input signal	72	The electrical signal fed to the control at the ST08 plug of the mainboard or the ST05 plug of the relay board. Depending on the signal characteristic (Voltage, current or resistivity progress), a certain pin of the corresponding plug is used. The signal range of the input signal (e.g. 0...10V) is to be adapted by setting of the related parameter. Using the Correction_x_signal [49] parameters, the output signal of a humidity sensor may be calibrated.
External controller	73	The control uses the output signal of an external controller to control the power element for steam generation. The input level of the control can be adapted to different signal types and value ranges. Other possible input signals are the output signal of a humidity sensor (in connection with the internal PI controller), the switching contact of a → <i>Hygrostat</i> [6] (for → <i>1 step operation</i> [44]) and a → <i>Software command</i> [12] via the → <i>Communication interface</i> [13].
Dropout delay	74	By assigning the "8" value to one of the relay contacts, a control signal for the delayed closing of a steam valve is made available for pressure reduction. The dropout delay is set with the "Humidification_off_delay" parameter. Factory default is 60 s.
Main contactor	75	The installed main contactors are labelled K1...K4. The operating cycles of the main contactor(s) are monitored and compared with the value specified by the manufacturer for the expected service life. When the stored value is reached, the message "Service_main_contactor" is generated. After the main contactor has been replaced, the status message must be deleted, for example using the → <i>Main_contactor_K1_Reset</i> = "1" parameter.
ELDB	77	Electrode steam humidifier.
HKDB	78	Heater steam humidifier.
HVAC	79	Heating, Ventilation, Air Condition: Generic term in the English language area for air conditioning equipment.
Virtual interlock (safety) system	86	If control via → <i>Communication interface</i> [13] was selected, software is used to place a logical switch in series with the hardware interlock (safety) system. This switch can be opened and closed via → <i>Software commands</i> [12]. If the hardware interlock (safety) system is closed and the switch is opened via software control command, steam production is stopped and the unit is placed in "Remote switch-off" status.
Supply voltage	89	The units are designed for connection to supply voltage ranges (e.g. 380 to 415 VAC in case of a 400 VAC unit, s. name plate)
Weekly timer	91	The timer makes it possible to program 2 periods per day of the week, each defined by a start time and an end time. The humidity set-value can be preset for each time period.
Recording	93	The control can record 10 parameters internally on a rolling basis. Snapshots of the unit status are carried out at intervals of 10 s, which can be helpful for troubleshooting. When the storage space is filled, a new set of parameter overrides the oldest entry. The complete record can be saved to a USB stick with NTFS formatting.
Slave	94	The unit functions as a slave in a master/slave arrangement, where a control unit (master) can control up to 3 slaves for the purpose of improving the output performance of the entire system. The slaves are switched sequentially. The output signal of the master on terminals 12, 13 is connected to the input terminals of the 1. slave. The input signal assignment of the 1st slave (and all subsequent ones) must be set to "Slave", this also applies to the output signal assignment for the master and all slaves.

Glossary ctd. (4)

Term	[Index]	Explanation
Warning message	95	The electrodes (for the → <i>ELDB</i> [77]), the blow-down pump and the solenoid valves are items with limited service life due to wear and tear. They must be checked during maintenance works and replaced if required. To avoid unplanned maintenance requirements, alerts can be set up for the respective items, which are activated when a defined state of wear is reached. The criteria for the alerts to be triggered can be defined in three stages each through the sensitivity setting.
PI controller	96	Internal controller with control characteristics which contain a Proportional part and an Integral part. Both parts can be changed as parameters.
Digital input	97	Digital input on the mainboard and on the relay boards for switching functions. A logical meaning (e.g. timer start) is assigned to the digital input via the → <i>Digital_input_function</i> [98] parameter. The digital input must be wired on-site in accordance with its use, e.g. with a → <i>Pushbutton</i> [106] or a → <i>Switch (NO)</i> [102] against an → <i>Auxiliary voltage</i> [105]. When the → <i>Auxiliary voltage</i> [105] is applied (short-term via a → <i>Pushbutton</i> [106] or permanent via a → <i>Switch (NO)</i> [102]), as required in accordance with → <i>Digital_input_function</i> [98] parameter setting), the switching function is carried out.
Digital_input_function	98	Determines which function will be executed if the → <i>Digital input</i> [97] on the mainboard or one of the relay boards is loaded externally with level "1" (= 12 V).
Nominal power output	99	The steam output range given on the name plate derived from the allowable range of supply voltages
Power section	100	That part of the unit that makes the energy conversion from the current supplied into steam output
Load shedding	101	Load shedding can be set up by assigning the → <i>Function_digital_input</i> [98] "Power limitation" to the → <i>Digital input</i> [97]. When the → <i>Digital input</i> [97] is then then connected to an → <i>Auxiliary voltage</i> [105] by means of a → <i>Switch (NO)</i> [102], → <i>Max. steam output</i> [43] is reduced by the percentage set up in the "Δ power limitation" parameter. After withdrawal of the voltage normal operation is reestablished.
Switch (NO)	102	Electrical switch with Normally Open contacts
Steam_down_time_min.	103	Steam-down time between fillings is continuously monitored. If the minimum steam-down time set falls below the value set up several times in a row, an indication exists that the cylinder water conductivity has risen to an extend non tolerable. For conductivity reduction, → <i>Dilution</i> [23] is triggered (only → <i>ELDB</i> [77]).
Slave_hysteresis	104	In order to avoid unnecessary frequent switching on and off of → <i>Slave</i> [94] units (as required by the output demand) or an oscillating tendency, switching is made with a hysteresis. Example: One Master controls one Slave. Switching on the slave without hysteresis would occur at 50% output demand, same situation for switching the slave off. With a 1% hysteresis, switching on the slave is at 51% output demand whereas switching off is at 49%. By this, instability of the switch-off point is accomplished.
Auxiliary voltage	105	DC voltage in the range of 5...20V for activating the → <i>Digital input</i> [97] via a → <i>Pushbutton switch</i> [106] or a → <i>Switch</i> [102]. +20 VDC is available on Pin 3 of ST08 (mainboard) or ST05 (relay board). The auxiliary voltage is required to switch the → <i>Digital_input</i> [97] on the mainboard or a relay board in order to trigger the function defined by setting the → <i>Function_digital_input</i> [98] (e.g. switch on ECO mode).
Pushbutton	106	Electrical switch the contacts of which remain closed as long as the pushbutton is pushed
Fully automatic deadleg flushing	107	For "fully automatic" → <i>Deadleg flushing</i> [27], an additional relay must be implemented that allows for switching the intake solenoid valve even when the → <i>Interlock (safety) system</i> [11] is open. Control of this additional relay is either by the base relay on the mainboard or a coupling relay. The relay used for this function must have "68" as the assignment.

9. Technical Data

Technical specifications FlexLine electrodes													
Unit type	FLE05		FLE10	FLE15	FLE20	FLE25	FLE30	FLE40	FLE50	FLE65	FLE80	FLE100	FLE130
Steam output [kg/h]	4,4-4,8		9,5-10,4	14,3-15,6	19,0-20,8	24,0-26,0	28,5-31,2	38,2-41,7	47,8-52,2	61,8-67,5	76,2-83,4	2 x 95,4-104,2	2 x 124,0-135,0
Electrical supply ⁽¹⁾ V/phases/Hz	220-240/1/N/50-60		380-415/3/N/50-60										
Power rating [kW]	3,3-3,6		7,1-7,8	10,7-11,7	14,3-15,6	18-19,5	21,4-23,4	28,6-31,3	35,9-39,2	46,3-50,6	2 x 28,6-31,2	2 x 35,8-39,1	2 x 46,3-50,6
Nominal current [A]	15		10,8	16,3	21,7	27,2	32,5	43,5	54,5	70,4	2 x 43,5	2 x 54,5	2 x 70,4
Circuit Protection [A] ⁽⁴⁾	1 x 16		3 x 16	3 x 20	3 x 32	3 x 32	3 x 40	3 x 50	3 x 63	3 x 80	2 x 3 x 50	2 x 3 x 63	2 x 3 x 80
Number of steam cylinder			1										
Control			Touch										
Control voltage, internal			220-240/1/N/50-60										
Control current: [A]			2,5										
Steam hose connection [mm]	1 x 25		1 x 40		1 x 40 with Y		2 x 40		2 x 40 with Y		4 x 40		
Condensate hose connection [mm]			1 x 12		695		750		785		750		4 x 12
Height ⁽⁶⁾ [mm]	535												785
Width ⁽⁶⁾ [mm]			540				580		640		1090		1170
Depth ⁽⁶⁾ [mm]			320				355		420		355		420
Water installation			Water / tap water (different qualities)										
			1 bis 10bar (100 x 10³ bis 1000 x 10³ Pa), with 3/4" connection for external thread										
Drain water connection			Connection Ø 1 1/4"										2x Connection Ø 1 1/4"

⁽¹⁾Other voltages upon request.

⁽⁴⁾Multiply power input by 1.1 after full blow-down. Note overload capacity of automatic breakers. If necessary, select the next higher rating.

⁽⁶⁾Outer dimensions of width and depth. Height incl. drain connection.


Technical specifications FlexLine Heater											
Unit type	FLH03	FLH06	FLH09	FLH15	FLH25	FLH30	FLH40	FLH50	FLH80	FLH100	
Steam output [kg/h]	2,7-3,3	5,5-6,5	8,2-9,8	13,7-16,4	22,7-27,1	27,4-32,7	36,5-43,5	45,5-54,3	73,0-87,0	91,0-108,5	
Electrical supply ⁽¹⁾ V/phases/Hz	220-240/1/N/50-60										
Power rating [kW]	2,1-2,4	4,1-4,9	6,2-7,3	10,3-12,3	17,1-20,3	20,6-24,5	27,3-32,6	34,1-40,7	2 x 27,3-32,6	2 x 34,1-40,7	
Nominal current [A]	9,4-10,2	18,7-20,4	16-17,5	15,6-17,1	25,9-28,3	31,2-34,1	41,5-45,4	51,8-56,6	2 x 41,5-45,4	2 x 51,8-56,6	
Circuit Protection [A]	1 x 16	1 x 25	3 x 16	3 x 20	3 x 32	3 x 35	3 x 50	3 x 63	2 x 3 x 50	2 x 3 x 63	
Number of steam cylinder	1										
Control	Touch										2
Control voltage, internal	220-240 V/1/N/50-60Hz										
Control current: [A]	2,5										
Steam hose connection [mm]	1 x 25										
Condensate hose connection [mm]	1 x 12										
Height ⁽⁶⁾ [mm]	535										
Width ⁽⁶⁾ [mm]	540										
Depth ⁽⁶⁾ [mm]	320										
Water installation	Fully demineralized water / cleaned condensate / partially softened Water / tap water (different qualities)										
Drain water connection	1 bis 10bar (100 x 10³ bis 1000 x 10³ Pa), 13mm Hose Connection Ø 1 1/4"										
	2x Connection Ø 1 1/4"										





⁽¹⁾ Other voltages upon request.





⁽⁶⁾ Outer dimensions of width and depth. Height incl. drain connection.









This page intentionally left blank

Screen



Active screen area	Use
	Main display for operating values, navigation using the scroll keys ^{*)} .
 ^{*)}	<p>Scroll buttons can be used to display the following operating values:</p> <ul style="list-style-type: none"> • Humidity_actual_value [%] • Humidity_set-value [%] ^{1),2)}; touching it opens a screen keyboard ^{*)} that allows for changing the set value • Steam_actual_unit [kg/h] • Steam_output_max. [%] • Demand [%] • Control_signal_internal [%] • Output_signal • Current_actual_cyl. 1[A] (Electrode steam humidifiers only) • Current_actual_cyl. 2 [A] (Electrode steam humidifier double cyl. units only) • Waterlevel_cyl. 1 [mm] (Heater steam humidifiers only) • Waterlevel_cyl. 2 [mm] (Heater steam humidifier double cylinder units only) <p>¹⁾only when „PI controller“ is set ²⁾ not in „Weekly timer“ mode; exemption: when „ECO“ is selected as the steam production mode, the humidity set-value is output in „Weekly timer“ mode as well.</p>
^{**)} 	<p>Screen keyboard for changing the humidity set value; is displayed when the humidity set value display is touched; allows direct changing of the set value.</p> <p>Saving of the input by touching the confirmation tick in the upper right corner, exit without saving by touching the „X“ in the upper left corner.</p>
	<p>Button to call up set-up mode (via password).</p> <p>Password „000“ -> operating functions of user level (see Section 5.5)</p> <p>Password „010“ -> operating functions of operator level (see Section 5.7)</p>

Active screen area	Use
  	In the event of a fault or a service message, the relevant display field is shown instead of the HygroMatik logo. Touching it opens the unit info screen (see Section 5.7).
	Unit info screen (see Section 5.9) for the display of error and service messages in plain text. Is displayed by touching the error or service message.

Icon	Status	Meaning
	dark bright flashes	Steam generation active No steam generation Fault steam generation
	dark bright flashes	Main contactor switched Main contactor not switched Fault main contactor
	dark bright flashes	Filling active No filling Fault filling
	dark bright flashes	Blow-down active No blow-down Fault blow-down <u>Manual blow-down</u> A manual blow-down can be triggered by touching the icon. Touching the icon again stops the manual blow-down. Max. blow-down time corresponds to the parameter setting for full blow-down
	dark bright flashes	Demand has been made Demand has been made Fault demand
	dark bright	Interlock (safety) system closed Interlock (safety) system open
	dark bright	Virtual interlock (safety) system closed (via communication interface) Virtual interlock (safety) system open
	dark flashes	Operating mode display Unit is in the initialisation phase



HygroMATIK®

HygroMatik GmbH
Lise-Meitner-Str. 3
24558 Henstedt-Ulzburg
Germany

T +49 4193 895-0
F +49 4193 895-33
hy@hygromatik.de
www.hygromatik.com

A Member of the **spirax**
/sarco group